

NO. OF COPIES RECEIVED		
DISTRIBUTION		
STATE		
FEE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	

7. Unit Agreement Name	

8. Farm or Lease Name	
Davis	
9. Well No.	
1	
10. Field and Pool, or Wildcat	
Wildcat	
12. County	
Roosevelt	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- Dry Hole
2. Name of Operator Read & Stevens, Inc.
3. Address of Operator P. O. Box 2126, Roswell, New Mexico 88201
4. Location of Well UNIT LETTER P, 660 FEET FROM THE South LINE AND 660 FEET FROM THE East LINE, SECTION 25 TOWNSHIP 7-South RANGE 34-East NMPM.
15. Elevation (Show whether DF, RT, GR, etc.) 4264.6' GR - 4275' RKB

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>
OTHER <input type="checkbox"/>	OTHER <input type="checkbox"/>
PLUG AND ABANDON <input checked="" type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
CHANGE PLANS <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

TD 4725' 1m. w/ perfs. @ 4395'-4640.5' overall. On production tests perfs. have yielded formation water w/ very slight shows of oil. Propose to plug and abandon as follows:

1. Circulate hole full of good mud (9.5# wt.)
2. Set cast iron bridge plug above perfs. @ 4350' & spot 35' cement plug on top of bridge plug.
3. Cut and pull 4 1/2" casing where free. Top of cement behind 4 1/2" casing @ 3400'.
4. Set 100' cement plug 1/2 in and 1/2 out of 4 1/2" casing stub.
5. Set 100' cement plug @ base of Salado Salt @ 2402'.
6. Set 100' cement plug @ top of Salado Salt @ 2204'.
7. Set 100' cement plug 1/2 in and 1/2 out of 8 5/8" casing shoe @ 414'.
8. Set 10 sx. cement plug at surface and install regulation marker.

E. Jones 8/26/77

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED *John L. Anderson* TITLE Agent DATE 8-24-76

APPROVED BY _____ TITLE _____ DATE _____

CONDITIONS OF APPROVAL, IF ANY:

REMOVED

SEP 2 1978

U.S. GOVERNMENT PRINTING OFFICE
WASHINGTON, D.C.