

Submit 3 Copies
to Appropriate
District Office

State of New Mexico
Energy, Minerals and Natural Resources Department

Form C-103
Revised 1-1-89

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION
P.O. Box 2088
Santa Fe, New Mexico 87504-2088

WELL API NO. 30-041-20686

5. Indicate Type of Lease
STATE ☐ FEE ☐

6. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS RECEIVED
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT"
(FORM C-101) FOR SUCH PROPOSALS.)

7. Lease Name or Unit Agreement Name

1. Type of Well: MAY 22 '89
OIL WELL ☐ GAS WELL ☐ OTHER ☐

Tucker

2. Name of Operator
Wallace Oil & Gas, Inc. O.C.D. ARTESIA OFFICE

8. Well No.

1

3. Address of Operator
50 Penn Place, Suite 850, Oklahoma City, OK 73118

9. Pool name or Wildcat

Wildcat

4. Well Location
Unit Letter K : 1980 Feet From The South Line and 1980 Feet From The West Line
Section 5 Township 7 S Range 33 E NMPM Roosevelt County

10. Elevation (Show whether DF, RKB, RT, GR, etc.)

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input checked="" type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>		CASING TEST AND CEMENT JOB <input type="checkbox"/>	
OTHER: <input type="checkbox"/>		OTHER: <input type="checkbox"/>	

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Set CIBP @ 4095'. Cap w/ 10 sks. of cement.
2. Load hole with mud.
3. Spot 25sk. cement plug @ 3060' and tag @ 2955'.
4. Spot 30 sk. cement plug @ 2464' and tag @ 2349'.
5. Spot 30 sk. cement plug @ 1900'.
6. Spot 30 sk. cement plug @ 450'.
7. Spot 10 sk. cement plug @ surface and install P & A marker.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Raymond Maldonado TITLE P & A Supervisor DATE 5-10-89
TYPE OR PRINT NAME Raymond Maldonado Cementer, Baber Well Servicing Co. TELEPHONE NO. 505-393-5516

(This space for State Use)

APPROVED BY Eddie W. Seay TITLE Oil & Gas Inspector DATE AUG 23 1989

CONDITIONS OF APPROVAL, IF ANY: