

UNITED STATES

ROSWELL RESOURCE AREA

SUBMIT IN TRIPLICATE
(Other Instructions
reverse side)Budget Bureau No. 1004-1001
Expires August 31, 1985

DEPARTMENT OF THE INTERIOR

BUREAU OF LAND MANAGEMENT

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT..." for such proposals.)

1. ☒ OIL WELL ☐ GAS WELL ☐ OTHER

2. NAME OF OPERATOR
M & W OF LOVINGTON, INC.

3. ADDRESS OF OPERATOR
BOX 922 LOVINGTON, N.M. 88260 (95) 369 8798

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.
See also space 17 below.)
At surface
1650' FSL 330' FEL

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)
4108

5. LEASE DESIGNATION AND SERIAL NO.
N.M. 52629 83624

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME
BOYD FEDERAL

9. WELL NO.
1

10. FIELD AND POOL, OR WILDCAT
SOUTH PRAIRIE SAN ANDRES

11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA
SEC. 17 T-8s R-36e

12. COUNTY OR PARISH
ROOSEVELET

13. STATE
N.M.

Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETE

ABANDON*

CHANGE PLANS

X

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

1. SET CIBP & 50' CEMENT PLUG @ 4700' & TAG.
- * 2. SET CEMENT PLUG @ 2250' - 1850' & TAG.
3. SET CEMENT PLUG @ 320' - 420' & TAG. OK to eliminate (PWC).
4. SET CEMENT PLUG @ 0' - 50'.
5. SET DRY HOLE MARKER.

* If $5\frac{1}{2}$ " casing cut & pulled at freepoint a 100' cmt. plug will be placed across the stub. The plug will need to be tagged.

If the $5\frac{1}{2}$ " casing is not cut & pulled the plug across from the $8\frac{5}{8}$ " casing shoe (needs to be 120' minimum, 2277' to 2157') will need to be placed both in and behind the $5\frac{1}{2}$ " casing. (PWC).

18. I hereby certify that the foregoing is true and correct

SIGNED

TITLE


DATE

(This space for Federal or State office use)

APPROVED BY

TITLE

CONDITIONS OF APPROVAL, IF ANY: As modified.



*See Instructions on Reverse Side