

Form 3160-5  
(June 1990)

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
BUREAU OF LAND MANAGEMENT

FORM APPROVED  
Budget Bureau No. 1004-0135  
Expires: March 31, 1993

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.  
Use "APPLICATION FOR PERMIT-" for such proposals

SUBMIT IN TRIPLICATE

1. Type of Well  
☒ Oil Well ☐ Gas Well ☒ Other ~~WATER~~

2. Name of Operator  
PLAINS PETROLEUM OPERATING COMPANY

3. Address and Telephone No.  
415 W. WALL, SUITE 1000 MIDLAND, TX 79701 915/683-4434

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)  
660' FNL & 1980' FEL, SEC. 13 (B), T8S, R37E

5. Lease Designation and Serial No.

7M 0044216

6. If Indian, Allottee or Tribe Name

7. If Unit or CA, Agreement Designation

8. Well Name and No.

BLUITT SA 13 FEDERAL #2

9. API Well No.

30-041-20851

10. Field and Pool, or Exploratory Area

Bluitt San Andres Associated

11. County or Parish, State

ROOSEVELT, NM

12. CHECK APPROPRIATE BOX(S) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION	TYPE OF ACTION	
<input checked="" type="checkbox"/> Notice of Intent	<input checked="" type="checkbox"/> Abandonment	<input type="checkbox"/> Change of Plans
<input type="checkbox"/> Subsequent Report	<input type="checkbox"/> Recompletion	<input type="checkbox"/> New Construction
<input type="checkbox"/> Final Abandonment Notice	<input type="checkbox"/> Plugging Back	<input type="checkbox"/> Non-Routine Fracturing
	<input type="checkbox"/> Casing Repair	<input type="checkbox"/> Water Shut-Off
	<input type="checkbox"/> Altering Casing	<input type="checkbox"/> Conversion to Injection
	<input type="checkbox"/> Other _____	<input type="checkbox"/> Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

1) GIH w/2-3/8" tbg work string & 5-1/2" x 2-3/8" packer. Circulate hole w/10 ppg mud. Set pkr @ 4600' KBM. Pressure test CIBP to 500 psi & tbg-csg annulus to 500 psi

2) Spot 15 sx Prem Plus cmt from 3000' back to 2850'

3) Perf 5-1/2" csg @ 550' KBM, set pkr on 2-3/8" tbg @ 485' and establish circulation out of 5-1/2" x 8-5/8" csg annulus w/10 ppg mud. Squeeze w/50 sx Prem Plus cmt & displace TOC to 485' *Log plug.*

4) Spot 20 sx Prem Plus cmt plug from 60' back to surface. Cut off all casings, weld on steel plate across all casings and install dry hole marker

14. I hereby certify that the foregoing is true and correct

Signed *Bonnie Rustand*

Title ADMINISTRATIVE ASSISTANT

Date 03/06/00

(This space for Federal or State office use)

Approved by \_\_\_\_\_

Title \_\_\_\_\_

Date \_\_\_\_\_

Conditions of approval, if any:

Title 18 U.S.C. Section 1001, makes it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

\*See Instruction on Reverse Side

GW

25  
MAR 2000  
Received  
Hobbs  
OCD

RECEIVED  
MAR 08 2000  
BLM  
ROSWELL, NM