

OPERATIONS PLAN
OGS OPERATING CO., INC.
Bluitt "8" Fed #2

1. Drill a 12 1/4" hole to approximately 365'.
2. Run 8 5/8" 24.0 ppf K-55 ST&C casing. Cement with 225 sx Class "C" cement containing 2% CaCl_2 . Run centralizers on every other joint above the shoe. Apply thread lock to bottom two joints and guide shoe.
3. Wait on cement for six hours prior to cutting off.
4. Nipple up and install a 3000 psi. Double Ram and Annular BOP system with choke manifold. WOC 18 hours prior to drilling out.
5. Test BOP system to 1000 psi with the rig pump. Test casing to 1500 psi.
6. Drill 7 7/8" hole to 4825'.
7. Either run 4825' of 4 1/2" 11.60 PPF LT&C casing and with DV tool @ $\pm 1700'$, or plug and abandon as per BLM requirements. If casing is run, cement first stage with 265 sx 50/50 Poz and 2nd stage with 300 sx "Light" followed by 100 sx Class "C" cement.

Exhibit "A"
OGS Operating Co., Inc.
Bluitt "8" Fed #2
Section 8, T-8-S, R-37-E
Roosevelt County, New Mexico