

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir. Use Form 9-331-C for such proposals.)

1. oil ☒ well gas ☐ well other ☐

2. NAME OF OPERATOR
TEXACO Inc.

3. ADDRESS OF OPERATOR
P. O. Box 728, Hobbs, NM 88240

4. LOCATION OF WELL (REPORT LOCATION CLEARLY. See space 17 below.)
AT SURFACE: **1980' FNL & 1980' FEL**
AT TOP PROD. INTERVAL: **(Unit Letter 'G')**
AT TOTAL DEPTH:

16. CHECK APPROPRIATE BOX TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

REQUEST FOR APPROVAL TO:	SUBSEQUENT REPORT OF:
TEST WATER SHUT-OFF <input type="checkbox"/>	<input type="checkbox"/>
FRACTURE TREAT <input type="checkbox"/>	<input type="checkbox"/>
SHOOT OR ACIDIZE <input type="checkbox"/>	<input type="checkbox"/>
REPAIR WELL <input type="checkbox"/>	<input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	<input type="checkbox"/>
MULTIPLE COMPLETE <input type="checkbox"/>	<input type="checkbox"/>
CHANGE ZONES <input type="checkbox"/>	<input type="checkbox"/>
ABANDON* <input checked="" type="checkbox"/>	<input type="checkbox"/>
(other)	

5. LEASE
NM-0338-A

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME
Little Lucky Lake Unit

RECEIVED

8. FARM OR LEASE NAME
Peery Federal

APR 23 1981

9. WELL NO.

1

O. C. D.

10. FIELD OR WILDCAT NAME
Little Lucky Lake Queen

ARTESIA, OFFICE

11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA
Sec. 29, T-15-S, R-30-E12. COUNTY OR PARISH
Chaves13. STATE
New Mexico

14. API NO.

15. ELEVATIONS (SHOW DF, KDB, AND WD)
3981' (DF)

(NOTE: Report results of multiple completion or zone change on Form 9-330)

APR 22 1981

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

1. Rig up.. Install BOP. *
2. Set CIBP @ 2100' & spot 20' cement on plug.
- ** 3. Perforate 9 5/8" Csg w/2-JS @ 475'. Establish circulation. Set cement retainer @ 375'.
4. Cement to surface through perfs @ 475' w/250 sx. Class 'H' Cement containing 2% CaCl.
5. Spot 10 sx. Cement plug @ surface.
6. Install dry hole marker. Clean location. Well abandoned, P&A.

Subsurface Safety Valve: Manu. and Type _____ Set @ _____ Ft.

18. I hereby certify that the foregoing is true and correct

SIGNED

TITLE **Asst. Dist. Mgr.** DATE **4-20-81**

APPROVED

this space for Federal or State office use)

APPROVED BY (Sgt. Sgd.) **PETER W. CHESTER** TITLE _____ DATE _____

CONDITIONS OF APPROVAL, IF ANY:

APR 22 1981

FOR

JAMES A. GILHAM
DISTRICT SUPERVISOR

**

See Instructions on Reverse Side

35' with dump trailer
or 25 sx min. if thru tubing
perf. at 1500' & squeeze with
75 sx cement to isolate salt base.

RECEIVED

APR 21 1981

U.S. GEOLOGICAL SURVEY
ARTESIA, NEW MEXICO