

COPIES RECEIVED		
DISTRIBUTION		
DATE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	
7. Unit Agreement Name	
Eastcap Queen	
8. Farm or Lease Name	
9. Well No.	
22	
10. Field and Pool, or Wildcat	
Caprock Queen	
12. County	
Chaves	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <input type="checkbox"/>
2. Name of Operator
AGUA, INC.
3. Address of Operator
Box #198, Artesia, New Mexico 88210
4. Location of Well
UNIT LETTER <u>D</u> , <u>660</u> FEET FROM THE <u>North</u> LINE AND <u>660</u> FEET FROM THE <u>West</u> LINE, SECTION <u>35</u> TOWNSHIP <u>14 South</u> RANGE <u>31 East</u> NMPM.
15. Elevation (Show whether DF, RT, GR, etc.)

16.

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>

SUBSEQUENT REPORT OF:

REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

This is a shut-in well. It is proposed to plug and abandon as follows:

Total Depth: 3142', PB to 3124'
Surface Casing: 8-5/8" 32# at 311 with 175 sx.
Prod. Casing: 5 1/2" 14# and 15.5# at 3137' w/200 sx.
Perforations: 3105-15'
Top of Salt: 1490'

Plugging Program: Set bridge plug above perforations and cap with 35' cement. Mud hole. Cut off 5 1/2" casing. Place 100' cement plug at top of stub. If stub is below top of salt, place 100' cement plug at top of salt. Place 100' cement plug to straddle bottom of 8-5/8" casing. Cap with 10 sacks of cement. Notify Oil Commission at start of operations.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Ralph L. Gray TITLE Consulting Engineer DATE June 27, 1974
APPROVED BY Joe D. Ranney TITLE SUPERVISOR DATE 10/1/74
CONDITIONS OF APPROVAL, IF ANY: