

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	

## SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <b>Injection well</b>		7. Unit Agreement Name	
2. Name of Operator		8. Farm or Lease Name	
<b>AMERICAN PETROFINA COMPANY OF TEXAS</b>		<b>North</b>	
3. Address of Operator		9. Well No.	
<b>Box 1311, Big Spring, Texas 79720</b>		<b>Tract 8 Well No. 8</b>	
4. Location of Well		10. Field and Pool, or Wildcat	
UNIT LETTER <b>H</b> , <b>1650</b> FEET FROM THE <b>North</b> LINE AND <b>330</b> FEET FROM		<b>Caprock Queen Lea</b>	
THE <b>East</b> LINE, SECTION <b>36</b> TOWNSHIP <b>12S</b> RANGE <b>31E</b> NMPM.			
15. Elevation (Show whether DF, RT, GR, etc.)		12. County	
<b>4394 Gr.</b>		<b>Chaves</b>	

16.

### Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

#### NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>

#### SUBSEQUENT REPORT OF:

REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Start work approximately 9-10-69

1. Spot 50 sx cement plug on bottom (TD 3016) through 2" EUE tubing using mud laden fluid as displacing medium.
2. Cut off 5-1/2" casing at 525'
3. Spot 25 sx cement plug at 525' (5-1/2" casing stub) and pull 5-1/2" casing.
4. Spot 25 sx cement plug at 239' (Bottom of 8-5/8" casing)
5. Set 10 sx cement plug in top of 8-5/8" casing and place 4-1/2" pipe marker.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>Cliff Chapman</u> <b>Cliff Chapman</b>	TITLE <u>Petroleum Engineer</u>	DATE <u>August 21, 1969</u>
APPROVED BY <u>[Signature]</u>	TITLE <u>[Signature]</u>	DATE <u>1969</u>
CONDITIONS OF APPROVAL, IF ANY:		