

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	
7. Unit Agreement Name	
D. Q. S. U.	
8. Farm or Lease Name	
Tract 29	
9. Well No.	
1	
10. Field and Pool, or Wildcat	
Caprock Queen	
12. County	
Chaves	

<p align="center">SUNDRY NOTICES AND REPORTS ON WELLS</p> <p align="center"><small>(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT --" (FORM C-101) FOR SUCH PROPOSALS.)</small></p>	
<p>1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <input type="checkbox"/></p>	
<p>2. Name of Operator</p> <p>Cities Service Oil Company</p>	
<p>3. Address of Operator</p> <p>Box 69, Hobbs, New Mexico 88240</p>	
<p>4. Location of Well</p> <p>UNIT LETTER <u>0</u> <u>710</u> FEET FROM THE <u>South</u> LINE AND <u>1980</u> FEET FROM THE <u>East</u> LINE, SECTION <u>2</u> TOWNSHIP <u>14S</u> RANGE <u>31E</u> NMPM.</p>	
<p>15. Elevation (Show whether DF, RT, GR, etc.)</p> <p>4398 GR</p>	

<p>16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data</p>	
<p>NOTICE OF INTENTION TO:</p> <p>PERFORM REMEDIAL WORK <input type="checkbox"/></p> <p>TEMPORARILY ABANDON <input type="checkbox"/></p> <p>PULL OR ALTER CASING <input type="checkbox"/></p> <p>OTHER <input type="checkbox"/></p>	<p>SUBSEQUENT REPORT OF:</p> <p>PLUG AND ABANDON <input checked="" type="checkbox"/></p> <p>CHANGE PLANS <input type="checkbox"/></p> <p>OTHER <input type="checkbox"/></p>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

- We propose to plug and abandon the above well in the following manner:
1. Set CI bridge plug in casing just above open hole. (5½' set @ 3047 w/100 sks)
 2. Set 25 sack cement plug on top of bridge plug.
 3. Load hole with mud laden fluid.
 4. Set 10 sack cement surface plug with a 4" dry hole marker.
 5. Clean location of all debris and equipment.

<p>18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.</p>	
<p>ORIGINAL SIGNED</p> <p>SIGNED <u>B. D. ROBERTSON</u></p>	<p>TITLE <u>District Admin. Supervisor</u></p> <p>DATE <u>5/4/70</u></p>
<p>APPROVED BY <u>[Signature]</u></p> <p>CONDITIONS OF APPROVAL, IF ANY:</p>	<p>TITLE <u>SUPERVISOR DISTRICT</u></p> <p>DATE <u>MAY 7 1970</u></p>

RECEIVED

MAY 6 1970

**OIL CONSERVATION COMM.
HCBBS, N. H.**