

| | |
|------------------------|--|
| NO. OF COPIES RECEIVED | |
| DISTRIBUTION | |
| SANTA FE | |
| FILE | |
| U.S.G.S. | |
| LAND OFFICE | |
| OPERATOR | |

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

| |
|--|
| 5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/> |
| 5. State Oil & Gas Lease No. - |
| 7. Unit Agreement Name D. Q. S. U. |
| 8. Farm or Lease Name Tract 21 |
| 9. Well No. 3 |
| 10. Field and Pool, or Wildcat Caprock Queen |
| 12. County Chaves |

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

| |
|---|
| 1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- Water Injection |
| 2. Name of Operator Cities Service Oil Company |
| 3. Address of Operator Box 69 - Hobbs, New Mexico 88240 |
| 4. Location of Well UNIT LETTER H , 1980 FEET FROM THE North LINE AND 660 FEET FROM THE East LINE, SECTION 2 TOWNSHIP 14S RANGE 31E NMPM. |

15. Elevation (Show whether DF, RT, GR, etc.)
-

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO:

| | |
|--|--|
| PERFORM REMEDIAL WORK <input type="checkbox"/> | PLUG AND ABANDON <input checked="" type="checkbox"/> |
| TEMPORARILY ABANDON <input type="checkbox"/> | CHANGE PLANS <input type="checkbox"/> |
| PULL OR ALTER CASING <input type="checkbox"/> | OTHER <input type="checkbox"/> |

SUBSEQUENT REPORT OF:

| | |
|---|---|
| REMEDIAL WORK <input type="checkbox"/> | ALTERING CASING <input type="checkbox"/> |
| COMMENCE DRILLING OPNS. <input type="checkbox"/> | PLUG AND ABANDONMENT <input type="checkbox"/> |
| CASING TEST AND CEMENT JOB <input type="checkbox"/> | OTHER <input type="checkbox"/> |

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

We propose to plug and abandon the above well in the following manner:

1. Set CI bridge plug in casing just above open hole.
2. Set 25 sack cement plug on top of bridge plug.
3. Load hole with mud laden fluid.
4. Cut and pull approx. 2000 of 5½" casing.
5. Set 100' cement plug, ½ in and ½ out of 5½" casing stub.
6. Set 100' cement plug at the top of the salt section.
7. Set 100' cement plug, ½ in and ½ out of 8 5/8" surface casing stub.
8. Set 10 sack cement surface plug with a 4' dry hole marker.
9. Clean location of all debris and equipment.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED _____ TITLE **District Admin. Supervisor** DATE **March 26, 1970**
APPROVED BY John W. Runyan TITLE _____ DATE _____
CONDITIONS OF APPROVAL, IF ANY:

OIL CONSERVATION COMM.
HOBBS, N. M.
MAR 27 1970

RECEIVED