

COPIES RECEIVED		
TRIBUTION		
FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease
State Fee
5. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- Water Injection	7. Unit Agreement Name Eastcap Queen
2. Name of Operator AGUA, INC.	8. Farm or Lease Name
3. Address of Operator Box #198, Artesia, New Mexico 88210	9. Well No. 1
4. Location of Well UNIT LETTER I , 1650 FEET FROM THE South LINE AND 560 FEET FROM THE East LINE, SECTION 22 TOWNSHIP 14 South RANGE 31 East NMPM.	10. Field and Pool, or Wildcat Caprock Queen
15. Elevation (Show whether DF, RT, GR, etc.)	12. County Chaves

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

This is a shut-in well. It is proposed to plug and abandon as follows:

Total Depth: 3106, plugged back to 3100'.
Surface casing: 8-5/8" 24# H-40 at 305' w/350 sx.
Prod. Casing: 5 1/2" 14# J-55 at 3102' w/134 sx.
Perforations: 3095-98
Top of Salt: 1256'.

Plugging Program: Set bridge plug above perforations and cap with 35' cement. Mud hole. Cut off 5 1/2" casing. Place 100' cement plug at top of stub. If stub is below top of salt, place 100' cement plug at top of salt. Place 100' cement plug to straddle bottom of 8-5/8" casing. Cap with 10 sacks of cement. Notify Oil Commission at start of operations.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Ralph L Gray TITLE Consulting Engineer. DATE June 26, 1974

APPROVED BY Joe D. Ramey TITLE SUPERVISOR DATE

CONDITIONS OF APPROVAL, IF ANY: