

NO. OF COPIES RECEIVED	
DISTRIBUTION	
ANTA FE	
FILE	
J.S.G.S.	
LAND OFFICE	
OPERATOR	

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	

## SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <b>Water Injection</b>		7. Unit Agreement Name
2. Name of Operator <b>Union Oil Company of California</b>		8. Farm or Lease Name <b>Tract 54</b> <b>Caprock Queen Unit, S.</b>
3. Address of Operator <b>P. O. Box 671 Midland, Texas 79701</b>		9. Well No. <b>9</b>
4. Location of Well UNIT LETTER <b>I</b> <b>660</b> FEET FROM THE <b>East</b> LINE AND <b>1650</b> FEET FROM THE <b>South</b> LINE, SECTION <b>28</b> TOWNSHIP <b>14S</b> RANGE <b>31E</b> NMPM.		10. Field and Pool, or Wildcat <b>Caprock Queen (Chaves)</b>
15. Elevation (Show whether DF, RT, GR, etc.)		12. County <b>Chaves</b>

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>
OTHER <input type="checkbox"/>	OTHER <input type="checkbox"/>
PLUG AND ABANDON <input checked="" type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
CHANGE PLANS <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

## PROPOSE TO PLUG AND ABANDON AS FOLLOWS:

Pump 50 sacks cement with 2% calcium chloride added through tubing. Spot plug over perforations in 5-1/2" casing 3013-3016'. Test plug to 1000 psi. Displace hole with mud. Pump 150 sacks cement with 2% calcium chloride added in 5-1/2" x 8-5/8" annulus and displace below casing head. Spot 10 sack cement plug in 5-1/2" casing 0' to 30'; cut off casing heads; weld on tapped steel plate; install dry hole marker and clean location.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.		
SIGNED <b>R.G. Ladd, Jr.</b>	TITLE <b>District Drilling Superintendent</b>	DATE <b>2-4-69</b>
APPROVED BY <b>[Signature]</b>	TITLE	DATE
CONDITIONS OF APPROVAL, IF ANY:		