

STATE OF NEW MEXICO
ENERGY AND MINERALS DEPARTMENT

OIL CONSERVATION DIVISION

P. O. BOX 2088

SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-78

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT --" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator Exxon Corporation	8. Form or Lease Name Tobac State Oil Com A
3. Address of Operator P. O. Box 1600, Midland, Texas 79702	9. Well No. 1
4. Location of Well UNIT LETTER <u>L</u> , <u>660</u> FEET FROM THE <u>West</u> LINE AND <u>2130</u> FEET FROM THE <u>South</u> LINE, SECTION <u>20</u> TOWNSHIP <u>8S</u> RANGE <u>33E</u> NMPM.	10. Field and Pool, or Wldcat Tobac Penn
15. Elevation (Show whether DF, RT, GR, etc.) 4393' DF	12. County Chaves

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input checked="" type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

- Run free point - cut and pull 4 1/2" csg.
- Spot 100' cmt plug across following intervals:
4 1/2" csg cut at 7300', top of San Andres at 4200' ⁺, across 7 5/8" csg shoe at 3617'. Verify plug tops.
- Run free point - cut and pull 7 5/8" csg at 1400' ⁺.
- Spot 100' cmt plugs across intervals: 7 5/8" cut, across 10 3/4" csg shoe at 407'.
10 sx plug at surface.
- Install dry hole marker as required by NMOCC.
- C-103 will be forwarded when location is cleaned and levelled.

100' PLUG AT 4987

THIS APPLICATION MUST BE MODIFIED 24
HOURS PRIOR TO THE BEGINNING OF
PLANNED OPERATIONS FOR THE C-103
TO BE APPROVED.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>J. A. Lucas</u>	TITLE <u>Sr. Administrator</u>	DATE <u>February 8, 1983</u>
ORIGINAL SIGNED BY JERRY SEXTON		
APPROVED BY <u>Jerry Sexton</u>	TITLE <u>District Supervisor</u>	DATE <u>JUN 14 1983</u>
CONDITIONS OF APPROVAL, IF ANY:		

RECEIVED

FEB 11 1983

O.C.D.
HOBBS OFFICE