

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	
B-8638	

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <input type="checkbox"/> Temporarily Abandoned		7. Unit Agreement Name
2. Name of Operator Beren Corporation		8. Farm or Lease Name Levick State
3. Address of Operator 1776 Lincoln Street, Suite 601, Denver, Colorado 80203		9. Well No. 2
4. Location of Well UNIT LETTER G, 17 FEET FROM THE 9 LINE AND 17 FEET FROM THE LINE, SECTION 20 TOWNSHIP 8S RANGE 33E NMPM.		10. Field and Pool, or Wildcat Tobac Penn
15. Elevation (Show whether DF, RT, GR, etc.) 4398 DF		12. County Chaves

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

We propose an attempt to repair collapsed 4½" casing in this well and return to production status. However, if unsuccessful, we plan to plug and abandon the well in the following manner. We plan to start work upon approval.

1. Run tubing to collapse in 4½" casing @5750', spot 100 SKS. Cement and displace to perforations @8946-65' with mud laden brine.
2. Run and set abandonment plug in 4½" casing above collapse @5750'. Load hole with mud laden brine and spot 100' cement plug.
3. Cut off 4½" casing at free point and spot 100' cement plug in top of cut off casing.
4. Pull 4½" casing to 3650' and spot 100' cement plug at 7 5/8" casing shoe. Pull and lay down 4½" casing.
5. Remove casing head. Latch on to 7 5/8" casing, cut off at free point and pull.
6. Run tubing to top 7 7/8" stub and spot 100' cement plug. Pull tubing to 393' and spot 100' cement plug at 10 3/4" casing shoe.
7. Cut off casing head and cap with 10 sxs cement and install dry hole marker.
8. Cut dead men and clean location.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Joe D. Ramsey Manager
TITLE Production & Engineering DATE October 29, 1974

APPROVED BY Joe D. Ramsey Dist. I, Supv.
TITLE _____ DATE _____

CONDITIONS OF APPROVAL, IF ANY: