

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. E-8253
7. Unit Agreement Name
8. Farm or Lease Name State 30
9. Well No. 3
10. Field and Pool, or Wildcat Tobac (Penn.)
12. County Chaves

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input checked="" type="checkbox"/> Dry Hole
2. Name of Operator Signal Oil and Gas Company
3. Address of Operator 509 W. Texas Avenue, Midland, Texas
4. Location of Well UNIT LETTER A 660 FEET FROM THE North LINE AND 660 FEET FROM THE East LINE, SECTION 30 TOWNSHIP 8-S RANGE 33-E NMPM.
15. Elevation (Show whether DF, RT, GR, etc.) G.L. 4398

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input checked="" type="checkbox"/> Reenter and test San Andres Zone

SUBSEQUENT REPORT OF:

REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input checked="" type="checkbox"/> Temporary Abandonment

Approved December 24, 1964.

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Work commenced 10-25-66.

1. Run bit to 4400' and circulate hole clean
2. Run Lynnes straddle packers and set top packer at 4315' and bottom packer at 4350'.
3. Acidize open hole 4315'-4350' w/500 gal acid and swab test.
 - a. If test proves inadequate recovery, pull packers and plug and abandon.
 - b. If test proves adequate recovery:
 - 1) Pull packer.
 - 2) Cement 900' of 5-1/2" liner at 4370'.
4. W.O.C. 12 hours.
5. Perforate liner at 4325'-4327' and 4331'-4341' w/1 shot/ft.
6. Run packer on 2" tubing and acidize w/1000 gal acid.
7. Swab test and pull tubing.
8. Frac w/50,000 gal and 40,000 lbs sand.
9. Place on production.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED F. G. Brown

TITLE Production Engineer

DATE 10-26-66.

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY:

1. The first part of the document is a list of the names of the persons who have been appointed to the various offices of the city of New York.

2. The second part of the document is a list of the names of the persons who have been appointed to the various offices of the city of New York.

3. The third part of the document is a list of the names of the persons who have been appointed to the various offices of the city of New York.

4. The fourth part of the document is a list of the names of the persons who have been appointed to the various offices of the city of New York.

5. The fifth part of the document is a list of the names of the persons who have been appointed to the various offices of the city of New York.