

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

MAY 15 8 00 PM '67

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. E-8253
7. Unit Agreement Name
8. Farm or Lease Name State 30
9. Well No. 4
10. Field and Pool, or Wildcat Tobac (Penn.)
12. County Chaves

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER-
2. Name of Operator Signal Oil and Gas Company
3. Address of Operator 125 Central Building, Midland, Texas
4. Location of Well UNIT LETTER E, 1880 FEET FROM THE north LINE AND 560 FEET FROM THE west LINE, SECTION 30 TOWNSHIP 8-S RANGE 33-E NMPM.
15. Elevation (Show whether DF, RT, GR, etc.) 4399 K. B.

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Casing	Depth	Cement	Cement Top	Perforations
10-3/4	376'	260 sx	Surface	None
7-5/8	3655'	300 sx	2960' (Temp. survey)	None
4-1/2	9110'	300 sx	7000' (calculated)	9049-9052 9060-9067

Proposed Procedure to Plug and Abandon

1. Spot 25 sx plug at 9089 ft.
2. Cut off 4-1/2" at 4500' and pull.
3. Spot 25 sx plug at 4500' in stub of 4-1/2" casing and at 3655' in bottom of 7-5/8" casing.
4. Cut off 7-5/8" casing at 2800' and pull.
5. Spot 25 sx plug at 2800' in stub of 7-5/8" casing.
6. Spot 25 sx plug in bottom of 10-3/4" casing at 376'.
7. Spot 7/8" sx plug in 10-3/4" casing at surface.
8. Cap well and install marker, clear location.

Work will begin upon approval, approximately May 22, 1967.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>L. G. Hill</u>	TITLE <u>Production Engineer</u>	DATE <u>5-12-67</u>
APPROVED BY <u>[Signature]</u>	SIGNED BY <u>[Signature]</u>	DATE <u> </u>

CONDITIONS OF APPROVAL, IF ANY:

Spot 25 sx plug at 9089 ft. 5/15/67