

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. K-2779

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- 2. Name of Operator Champlin Petroleum Company	7. Unit Agreement Name
3. Address of Operator P. O. Box 7946 Midland, Texas 79708-0946	8. Farm or Lease Name State 6-8-33
4. Location of Well UNIT LETTER C, 660 FEET FROM THE North LINE AND 1980 FEET FROM THE West LINE, SECTION 6 TOWNSHIP 8-S RANGE 33-E NMPM.	9. Well No. 3
10. Field and Pool, or Wildcat Chaveroo (San Andres)	
15. Elevation (Show whether DF, RT, GR, etc.) 4475.5 KB	12. County Chaves

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Well Uneconomical to Produce.

Proposed Plugging Procedure:

1. Set CIBP @ 4000' ±.
2. RIH w/tbg & displace hole w/10# mud.
3. Spot 50' cement on top of CIBP.
4. Determine free point on 4-1/2" OD csg.
5. Cut off casing above free pt. (usually 1000'-1100'). Pull & LD csg.
6. RIH w/tbg & spot 100' stub plug centered at top of casing stub.
7. PU tbg & spot 100' plug centered at base of surface pipe (364') - Tag plug.
8. Spot 50' surface plug & install dry hole marker.

San Andres perms 4162'-4366'
Top of Fish @ 4030'

THIS IS A TRUE AND CORRECT COPY OF THE ORIGINAL FILED IN THE OFFICE OF THE COMMISSIONER OF OIL & GAS FOR THE STATE OF NEW MEXICO TO BE ATTACHED TO THE APPLICATION.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.


SIGNED Eddie W. Seay TITLE Dist. Drlg. & Prod. Oper. Supt. DATE 9/10/85

APPROVED BY Oil & Gas Inspector TITLE _____ DATE SEP 12 1985
CONDITIONS OF APPROVAL, IF ANY:

State "6" Well No. 3
 660' FNL & 1980' FWL 6-8-33
 Chaveroo (San Andres) Field
 Chaves County, New Mexico

Elev. 4464.5 GR
 4474.5 DF
 4475.5 RDB

22-141 50 SHEETS
 22-142 100 SHEETS
 22-144 200 SHEETS



*Fish consists of 27' cut off Jt. of 2-3/8" tbg. 4-1/2"x2-3/8" TAC. 6 jts
 2-3/8" tbg. SN, PS & Mud Anchor.