

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- Temporarily Abandoned		7. Unit Agreement Name
2. Name of Operator UNION TEXAS PETROLEUM CORPORATION		8. Farm or Lease Name Crosby
3. Address of Operator 1300 Wilco Building, Midland, Texas 79701		9. Well No. 12
4. Location of Well UNIT LETTER D 660 FEET FROM THE North LINE AND 660 FEET FROM THE West LINE, SECTION 21 TOWNSHIP 8-S RANGE 30-E NMPM.		10. Field and Pool, or Wildcat Cato (San Andres) Ext.
15. Elevation (Show whether DF, RT, GR, etc.) 4120' DF		12. County Chaves

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1503.

- (1) 8 5/8" surface casing set @ 534', cemented w/300 sx. cement, circulated.
- (2) 4 1/2" production casing set @ 3599', cemented w/300 sx. cement, cement top at 2230'.
- (3) Casing perforations 3339-3370' (31 holes) and 3409-3421' (12 holes).
- (4) Spot cement plug from 3421-3000'.
- (5) Cut 4 1/2" casing at free point and spot cement plug 100' in 4 1/2" casing stub and 100' above.
- (6) Spot cement plug 100' below 8 5/8" casing and 100' in 8 5/8" casing.
- (7) Spot 10 sx. cement plug at surface and weld a 1/2" steel plate on 8 5/8" casing.
- (8) Install Dry hole marker in accordance with regulations.

NOTE: Work will be started immediately upon approval.
Mud laden fluid of 10#/Gal. will be left in well.

100' plug @ top salt
24 hr. notice.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Robert V. Plummer TITLE Operations Supt. Western Area DATE September 27, 1972

Orig. Signed by
Joe D. Ramey
Dist. L. Supv.

APPROVED BY _____ DATE SEP 29 1972