Form 9-331 (May 1963)		T IN TRIPL 'E instructions re	- Budget Bureau No. 4	
	DEPARTMENI OF THE INTERIOR Verse B	ide)	5. LEASE DESIGNATION AND SER	RIAL P
	GEOLOGICAL SURVEY		$-\frac{\text{NM } 0346362 \text{ (b)}}{6. \text{ if indian, allottee or the}}$	DE NA
SUN (Do not use this	DRY NOTICES AND REPORTS ON WEL form for proposals to drill or to deepen or plug back to a diffuse "APPLICATION FOR PERMIT—" for such proposals.)	LS erent reservoir.	U. IF INDIAN, ALLOITEE OF THE	
1. OIL X GAS WELL WELL			7. UNIT AGREEMENT NAME	
2. NAME OF OPERATOR			8. FARM OR LEASE NAME	
Atlantic Richf	ield Company		Woodman Federal	_
3. ADDRESS OF OPERATOR			9. WELL NO.	
<ul> <li>P. O. Box 1710, Hobbs, New Mexico 88240</li> <li>4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See also space 17 below.) At surface</li> </ul>		10 RIFLD AND ROOT OR WILDO	3 10. FIELD AND POOL, OR WILDCAT Cato San Andres	
at buildes			11. SEC., T., B., M., OR BLK. AND	<u> </u>
660' FNL & 660	)' FEL (Unit letter A)		SURVEY OR AREA 28-T8S-30E	
14. PERMIT NO.	15. ELEVATIONS (Show whether DF, RT, GR, etc.)		12. COUNTY OB PARISH 13. ST	TATE
	4145' GR		Chaves N	<u>.М</u> .
16.	Check Appropriate Box To Indicate Nature of N	otice, Report, or	Other Data	
:	NOTICE OF INTENTION TO:	SUBSE	QUENT REPORT OF:	
TEST WATER SHUT-O	BF PULL OR ALTER CASING WATE	B SHUT-OFF	REPAIRING WELL	
FRACTURE TREAT	MULTIPLE COMPLETE FRACT	URE TREATMENT	ALTERING CASING	
SHOOT OR ACIDIZE	ABANDON* SHOO	TING OR ACIDIZING	ABANDON MENT*	
REPAIR WELL	CHANGE PLANS (Othe		ts of multiple completion on Well	
(Other) Pl	ug & Abandon X	Completion or Recon	pletion Report and Log form.)	• 
8-5/8" OD 20#	3564'. Present perfs 3509-3547'. SP-40 csg set @ 281' & cmtd w/200 sx.		01 10	-
8-5/8" OD 20# 4-1/2" OD 9.5#	SP-40 csg set @ 281' & cmtd w/200 sx. # J-55 csg set @ 3600' & cmtd w/300 sx		0' FS.	-
8-5/8" OD 20# 4-1/2" OD 9.5# Propose to plu 1. Rig up csg	SP-40 csg set @ 281' & cmtd w/200 sx. # J-55 csg set @ 3600' & cmtd w/300 sx ng & abandon in the following manner: pullers & install BOP.		0' FS.	
8-5/8" OD 20# 4-1/2" OD 9.5# Propose to plu 1. Rig up csg 2. Run bit & c	SP-40 csg set @ 281' & cmtd w/200 sx. # J-55 csg set @ 3600' & cmtd w/300 sx ng & abandon in the following manner: pullers & install BOP. csg scraper to 3450'.		0'FS.	
8-5/8" OD 20# 4-1/2" OD 9.5# Propose to plu 1. Rig up csg 2. Run bit & c 3. Run cmt ret	SP-40 csg set @ 281' & cmtd w/200 sx. # J-55 csg set @ 3600' & cmtd w/300 sx ng & abandon in the following manner: pullers & install BOP. csg scraper to 3450'. cr & set @ 3450' & cmt w/100 sx cmt,		0' FS.	
8-5/8" OD 20# 4-1/2" OD 9.5# Propose to plu 1. Rig up csg 2. Run bit & c 3. Run cmt ret 4. Load hole w	SP-40 csg set @ 281' & cmtd w/200 sx. # J-55 csg set @ 3600' & cmtd w/300 sx ng & abandon in the following manner: pullers & install BOP. csg scraper to 3450'. cr & set @ 3450' & cmt w/100 sx cmt, w/9# mud.		0' FS.	-
8-5/8" OD 20# 4-1/2" OD 9.5# Propose to plu 1. Rig up csg 2. Run bit & c 3. Run cmt ret 4. Load hole w 5. Cut off & r	SP-40 csg set @ 281' & cmtd w/200 sx. # J-55 csg set @ 3600' & cmtd w/300 sx ng & abandon in the following manner: pullers & install BOP. csg scraper to 3450'. cr & set @ 3450' & cmt w/100 sx cmt, w/9# mud. recover $4\frac{1}{2}$ " csg from free pt.	. тос @ 226	0'FS.	-
<ul> <li>8-5/8" OD 20#</li> <li>4-1/2" OD 9.5#</li> <li>Propose to plu</li> <li>1. Rig up csg</li> <li>2. Run bit &amp; c</li> <li>3. Run cmt ret</li> <li>4. Load hole w</li> <li>5. Cut off &amp; r</li> <li>6. Spot 30 sk</li> </ul>	SP-40 csg set @ 281' & cmtd w/200 sx. # J-55 csg set @ 3600' & cmtd w/300 sx ag & abandon in the following manner: pullers & install BOP. esg scraper to 3450'. cr & set @ 3450' & cmt w/100 sx cmt, w/9# mud. recover $4\frac{1}{2}$ " csg from free pt. cmt plug half in & half out of $4\frac{1}{2}$ " csg	. тос @ 226	0' FS.	-
<ul> <li>8-5/8" OD 20#</li> <li>4-1/2" OD 9.5#</li> <li>Propose to plu</li> <li>1. Rig up csg</li> <li>2. Run bit &amp; c</li> <li>3. Run cmt ret</li> <li>4. Load hole w</li> <li>5. Cut off &amp; r</li> <li>6. Spot 30 sk</li> <li>7. Spot 40 sk</li> </ul>	SP-40 csg set @ 281' & cmtd w/200 sx. # J-55 csg set @ 3600' & cmtd w/300 sx ng & abandon in the following manner: pullers & install BOP. csg scraper to 3450'. cr & set @ 3450' & cmt w/100 sx cmt, w/9# mud. recover $4\frac{1}{2}$ " csg from free pt. cmt plug half in & half out of $4\frac{1}{2}$ " cs cmt plug across top of salt @ 1000'.	. TOC @ 226 g stub.		
<ul> <li>8-5/8" OD 20#</li> <li>4-1/2" OD 9.5#</li> <li>Propose to plu</li> <li>1. Rig up csg</li> <li>2. Run bit &amp; c</li> <li>3. Run cmt ret</li> <li>4. Load hole w</li> <li>5. Cut off &amp; r</li> <li>6. Spot 30 sk</li> <li>7. Spot 40 sk</li> <li>8. Spot 40 sk</li> </ul>	SP-40 csg set @ 281' & cmtd w/200 sx. # J-55 csg set @ 3600' & cmtd w/300 sx ag & abandon in the following manner: pullers & install BOP. esg scraper to 3450'. cr & set @ 3450' & cmt w/100 sx cmt, w/9# mud. recover $4\frac{1}{2}$ " csg from free pt. cmt plug half in & half out of $4\frac{1}{2}$ " csg	. TOC @ 226 g stub.		
<ul> <li>8-5/8" OD 20#</li> <li>4-1/2" OD 9.5#</li> <li>Propose to plu</li> <li>1. Rig up csg</li> <li>2. Run bit &amp; c</li> <li>3. Run cmt ret</li> <li>4. Load hole w</li> <li>5. Cut off &amp; r</li> <li>6. Spot 30 sk</li> <li>7. Spot 40 sk</li> <li>8. Spot 40 sk</li> <li>9. Spot 10 sk</li> </ul>	SP-40 csg set @ 281' & cmtd w/200 sx. # J-55 csg set @ 3600' & cmtd w/300 sx ng & abandon in the following manner: pullers & install BOP. csg scraper to 3450'. cr & set @ 3450' & cmt w/100 sx cmt, w/9# mud. recover $4\frac{1}{2}$ " csg from free pt. cmt plug half in & half out of $4\frac{1}{2}$ " cs cmt plug across top of salt @ 1000'. cmt plug across 8-5/8" OD csg shoe @	. TOC @ 226 g stub. 281'.	RECEIV	
<ul> <li>8-5/8" OD 20#</li> <li>4-1/2" OD 9.5#</li> <li>Propose to plu</li> <li>1. Rig up csg</li> <li>2. Run bit &amp; c</li> <li>3. Run cmt ret</li> <li>4. Load hole w</li> <li>5. Cut off &amp; r</li> <li>6. Spot 30 sk</li> <li>7. Spot 40 sk</li> <li>8. Spot 40 sk</li> <li>9. Spot 10 sk</li> </ul>	SP-40 csg set @ 281' & cmtd w/200 sx. # J-55 csg set @ 3600' & cmtd w/300 sx ag & abandon in the following manner: pullers & install BOP. csg scraper to 3450'. cr & set @ 3450' & cmt w/100 sx cmt, w/9# mud. recover $4\frac{1}{2}$ " csg from free pt. cmt plug half in & half out of $4\frac{1}{2}$ " cs cmt plug across top of salt @ 1000'. cmt plug across 8-5/8" OD csg shoe @ cmt plug @ surface.	. TOC @ 226 g stub. 281'.	RECEIV FEB · 4 197	5
<ul> <li>8-5/8" OD 20#</li> <li>4-1/2" OD 9.5#</li> <li>Propose to plu</li> <li>1. Rig up csg</li> <li>2. Run bit &amp; c</li> <li>3. Run cmt ret</li> <li>4. Load hole w</li> <li>5. Cut off &amp; r</li> <li>6. Spot 30 sk</li> <li>7. Spot 40 sk</li> <li>8. Spot 40 sk</li> <li>9. Spot 10 sk</li> </ul>	SP-40 csg set @ 281' & cmtd w/200 sx. # J-55 csg set @ 3600' & cmtd w/300 sx ag & abandon in the following manner: pullers & install BOP. csg scraper to 3450'. cr & set @ 3450' & cmt w/100 sx cmt, w/9# mud. recover $4\frac{1}{2}$ " csg from free pt. cmt plug half in & half out of $4\frac{1}{2}$ " cs cmt plug across top of salt @ 1000'. cmt plug across 8-5/8" OD csg shoe @ cmt plug @ surface.	. TOC @ 226 g stub. 281'.	RECEIV	
<ul> <li>8-5/8" OD 20#</li> <li>4-1/2" OD 9.5#</li> <li>Propose to plu</li> <li>1. Rig up csg</li> <li>2. Run bit &amp; c</li> <li>3. Run cmt ret</li> <li>4. Load hole w</li> <li>5. Cut off &amp; r</li> <li>6. Spot 30 sk</li> <li>7. Spot 40 sk</li> <li>8. Spot 40 sk</li> <li>9. Spot 10 sk</li> <li>10. Erect regul</li> </ul>	SP-40 csg set @ 281' & cmtd w/200 sx. # J-55 csg set @ 3600' & cmtd w/300 sx ng & abandon in the following manner: pullers & install BOP. esg scraper to 3450'. Er & set @ 3450' & cmt w/100 sx cmt, w/9# mud. recover $4\frac{1}{2}$ " csg from free pt. cmt plug half in & half out of $4\frac{1}{2}$ " cs cmt plug across top of salt @ 1000'. cmt plug across 8-5/8" OD csg shoe @ cmt plug @ surface. lation dry hole marker, clean & level	. TOC @ 226 g stub. 281'.	RECEIV FEB - 4 197	
<ul> <li>8-5/8" OD 20#</li> <li>4-1/2" OD 9.5#</li> <li>Propose to plu</li> <li>1. Rig up csg</li> <li>2. Run bit &amp; c</li> <li>3. Run cmt ret</li> <li>4. Load hole w</li> <li>5. Cut off &amp; r</li> <li>6. Spot 30 sk</li> <li>7. Spot 40 sk</li> <li>8. Spot 40 sk</li> <li>9. Spot 10 sk</li> <li>10. Erect regul</li> </ul>	SP-40 csg set @ 281' & cmtd w/200 sx. # J-55 csg set @ 3600' & cmtd w/300 sx ng & abandon in the following manner: pullers & install BOP. esg scraper to 3450'. cr & set @ 3450' & cmt w/100 sx cmt, w/9# mud. recover 4 <sup>1</sup> / <sub>2</sub> " csg from free pt. cmt plug half in & half out of 4 <sup>1</sup> / <sub>2</sub> " cs cmt plug across top of salt @ 1000'. cmt plug across 8-5/8" OD csg shoe @ cmt plug @ surface. lation dry hole marker, clean & level t the foregoing is true and correct	g stub. 281'. location.	RECEIV FEB · 4 197 U. S. CEOLOGICAL SU ALTES.A, NEW MEXI	
8-5/8" OD 20# 4-1/2" OD 9.5# Propose to plu 1. Rig up csg 2. Run bit & c 3. Run cmt ret 4. Load hole w 5. Cut off & r 6. Spot 30 sk 7. Spot 40 sk 9. Spot 40 sk 9. Spot 10 sk 10. Erect regul	SP-40 csg set @ 281' & cmtd w/200 sx. # J-55 csg set @ 3600' & cmtd w/300 sx Ing & abandon in the following manner: pullers & install BOP. Esg scraper to 3450'. Cr & set @ 3450' & cmt w/100 sx cmt, w/9# mud. recover 4 <sup>1</sup> / <sub>2</sub> " csg from free pt. cmt plug half in & half out of 4 <sup>1</sup> / <sub>2</sub> " cs cmt plug across top of salt @ 1000'. cmt plug across 8-5/8" OD csg shoe @ cmt plug @ surface. Hation dry hole marker, clean & level t the foregoing is true and correct	g stub. 281'. location.	RECEIV FEB · 4 197 U. S. CEOLOGICAL SU A.TES.A, NEW MLXI	
8-5/8" OD 20# 4-1/2" OD 9.5# Propose to plu 1. Rig up csg 2. Run bit & c 3. Run cmt ret 4. Load hole w 5. Cut off & r 6. Spot 30 sk 7. Spot 40 sk 8. Spot 40 sk 9. Spot 10 sk 10. Erect regul	SP-40 csg set @ 281' & cmtd w/200 sx. # J-55 csg set @ 3600' & cmtd w/300 sx ng & abandon in the following manner: pullers & install BOP. esg scraper to 3450'. cr & set @ 3450' & cmt w/100 sx cmt, w/9# mud. recover 4 <sup>1</sup> / <sub>2</sub> " csg from free pt. cmt plug half in & half out of 4 <sup>1</sup> / <sub>2</sub> " cs cmt plug across top of salt @ 1000'. cmt plug across 8-5/8" OD csg shoe @ cmt plug @ surface. lation dry hole marker, clean & level t the foregoing is true and correct	g stub. 281'. location. g. Supv.	RECEIV FEB · 4 197 U. S. CEOLOGICAL SU ALTES.A, NEW MEXI	
8-5/8" OD 20# 4-1/2" OD 9.5# Propose to plu 1. Rig up csg 2. Run bit & c 3. Run cmt ret 4. Load hole w 5. Cut off & r 6. Spot 30 sk 7. Spot 40 sk 8. Spot 40 sk 9. Spot 10 sk 10. Erect regul	SP-40 csg set @ 281' & cmtd w/200 sx. # J-55 csg set @ 3600' & cmtd w/300 sx ng & abandon in the following manner: pullers & install BOP. esg scraper to 3450'. cr & set @ 3450' & cmt w/100 sx cmt, w/9# mud. recover 4½" csg from free pt. cmt plug half in & half out of 4½" cs cmt plug across top of salt @ 1000'. cmt plug across 8-5/8" OD csg shoe @ cmt plug @ surface. lation dry hole marker, clean & level t the foregoing is true and correct Marine TITLE Dist. Drl eral or State office use)	g stub. 281'. location. g. Supv.	RECEIV FEB · 4 197 U. S. CEOLOGICAL SU ALTES.A, NEW MEXI	
8-5/8" OD 20# 4-1/2" OD 9.5# Propose to plu 1. Rig up csg 2. Run bit & c 3. Run cmt ret 4. Load hole w 5. Cut off & r 6. Spot 30 sk 7. Spot 40 sk 8. Spot 40 sk 9. Spot 10 sk 10. Erect regul	SP-40 csg set @ 281' & cmtd w/200 sx. # J-55 csg set @ 3600' & cmtd w/300 sx ng & abandon in the following manner: pullers & install BOP. esg scraper to 3450'. Er & set @ 3450' & cmt w/100 sx cmt, w/9# mud. recover 4 <sup>1</sup> / <sub>2</sub> " csg from free pt. cmt plug half in & half out of 4 <sup>1</sup> / <sub>2</sub> " cs cmt plug across top of salt @ 1000'. cmt plug across 8-5/8" OD csg shoe @ cmt plug @ surface. Lation dry hole marker, clean & level the foregoing is true and correct	g stub. 281'. location. g. Supv.	RECEIV FEB · 4 197 U. S. CEOLOGICEL SU ANTES.A, NEW MLXI DATE 1/31/75	
8-5/8" OD 20# 4-1/2" OD 9.5# Propose to plu 1. Rig up csg 2. Run bit & c 3. Run cmt ret 4. Load hole w 5. Cut off & r 6. Spot 30 sk 7. Spot 40 sk 8. Spot 40 sk 9. Spot 10 sk 10. Erect regul	SP-40 csg set @ 281' & cmtd w/200 sx. # J-55 csg set @ 3600' & cmtd w/300 sx ng & abandon in the following manner: pullers & install BOP. esg scraper to 3450'. Er & set @ 3450' & cmt w/100 sx cmt, w/9# mud. recover 4 <sup>1</sup> / <sub>2</sub> " csg from free pt. cmt plug half in & half out of 4 <sup>1</sup> / <sub>2</sub> " cs cmt plug across top of salt @ 1000'. cmt plug across 8-5/8" OD csg shoe @ cmt plug @ surface. Lation dry hole marker, clean & level the foregoing is true and correct	g stub. 281'. location. g. Supv.	RECEIV FEB · 4 197 U. S. CEOLOGICEL SU ANTES.A, NEW MLXI DATE 1/31/75	
8-5/8" OD 20# 4-1/2" OD 9.5# Propose to plu 1. Rig up csg 2. Run bit & c 3. Run cmt ret 4. Load hole w 5. Cut off & r 6. Spot 30 sk 7. Spot 40 sk 8. Spot 40 sk 9. Spot 10 sk 10. Erect regul 18. I hereby certify that SIGNED (This space for Fedu APPROVED BY	SP-40 csg set @ 281' & cmtd w/200 sx. # J-55 csg set @ 3600' & cmtd w/300 sx hg & abandon in the following manner: pullers & install BOP. Esg scraper to 3450'. Er & set @ 3450' & cmt w/100 sx cmt, w/9# mud. Eccover 4 <sup>1</sup> / <sub>2</sub> " csg from free pt. cmt plug half in & half out of 4 <sup>1</sup> / <sub>2</sub> " cs cmt plug across top of salt @ 1000'. cmt plug across 8-5/8" OD csg shoe @ cmt plug @ surface. Lation dry hole marker, clean & level t the foregoing is true and correct Marine TITLE Dist. Dr] erel or State office use) TITLE	g stub. 281'. location. g. Supv. ADDITIONAL OR ROAD	RECEIV FEB · 4 197 U. S. CEOLOGICEL SU ANTES.A, NEW MLXI DATE 1/31/75	
8-5/8" OD 20# 4-1/2" OD 9.5# Propose to plu 1. Rig up csg 2. Run bit & c 3. Run cmt ret 4. Load hole w 5. Cut off & r 6. Spot 30 sk 7. Spot 40 sk 8. Spot 40 sk 9. Spot 10 sk 10. Erect regul 18. I hereby certify that SIGNED (This space for Fedd APFROVED BY	SP-40 csg set @ 281' & cmtd w/200 sx. # J-55 csg set @ 3600' & cmtd w/300 sx ng & abandon in the following manner: pullers & install BOP. esg scraper to 3450'. Er & set @ 3450' & cmt w/100 sx cmt, w/9# mud. recover 4 <sup>1</sup> / <sub>2</sub> " csg from free pt. cmt plug half in & half out of 4 <sup>1</sup> / <sub>2</sub> " cs cmt plug across top of salt @ 1000'. cmt plug across 8-5/8" OD csg shoe @ cmt plug @ surface. Lation dry hole marker, clean & level the foregoing is true and correct	g stub. 281'. location. g. Supv. ADDITIONAL OR ROAD	RECEIV FEB · 4 197 U. S. CEOLOGICEL SU ANTES.A, NEW MLXI DATE 1/31/75	

14

## RECEIVED

FEB 5 1975

O. C. C. ARTESIA, OFFICE

••

•



## RECEIVED

1

FEB - 4 1975

Blow Out Pr	eventer Program Di OGICAL SURVEY
Lease Name	Woodman Federal
Well No.	
Location	660' FNL & 660' FEL Sec 28, T8S, R30E, Chaves Co.

BOP to be tested before installed on well and will be maintained in good working condition during workover. All wellhead fittings to be of sufficient pressure to . operate in a safe manner.