

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Orig&2cc: CCC, Hobbs
cc: Regional Office
cc: File

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease
State <input type="checkbox"/> Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator SINCLAIR OIL & GAS COMPANY	8. Farm or Lease Name J. G. O'Brien 198
3. Address of Operator P. O. Box 1920, Hobbs, New Mexico 88240	9. Well No. 1
4. Location of Well UNIT LETTER <u>H</u> <u>660</u> FEET FROM THE <u>South</u> LINE AND <u>660</u> FEET FROM THE <u>West</u> LINE, SECTION <u>31</u> TOWNSHIP <u>8S</u> RANGE <u>30E</u> NMPM.	10. Field and Pool, or Wildcat Undesignated
15. Elevation (Show whether DF, RT, GR, etc.)	12. County Chaves

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐
TEMPORARILY ABANDON ☐
PULL OR ALTER CASING ☐
OTHER ☐

PLUG AND ABANDON ☒
CHANGE PLANS ☐
OTHER ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐
COMMENCE DRILLING OPNS. ☐
CASING TEST AND CEMENT JOBS ☐
OTHER ☐
ALTERING CASING ☐
PLUG AND ABANDONMENT ☐

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1703.

TO 3500', FBD 3462'. Presently completed in San Andres perms. 3240-3315' as shut-in well.

8-5/8"OD 20# SP-40 casing set @ 295' and cemented w/200 sks. to surface.

4-1/2"OD 9.5# J-55 casing set @ 3500' and cemented w/300 sacks. Cement approx. 2460' fr surf.

PROPOSE TO CHANGE PLANS APPROVED ON APRIL 12, 1968 AND PLUG AND ABANDON AS FOLLOWS:

Spot 25 to 30 sks. cement plug across perms. 3240-3315'. Fill hole w/mud laden material. Cut 4-1/2"OD casing off @ approx. 2450'. Spot 25 sks. cement plug in top of 4-1/2"OD casing stub. Spot 25 sks. cement plug bot'om of 8-5/8"OD casing @ 295'. Spot 10 sks. cement plug in top of 8-5/8"OD surface casing, install regulation dry hole marker, clean and level location.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>Tom Nemlow</u>	TITLE <u>Engineer</u>	DATE <u>4-17-68</u>
APPROVED BY <u>Joe O'Brien</u>	TITLE _____	DATE _____
CONDITIONS OF APPROVAL, IF ANY:		