

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. <b>B-10417 - 4</b>
7. Unit Agreement Name
8. Farm or Lease Name <b>Sunset - State</b>
9. Well No. <b>1</b>
10. Field and Pool, or Wildcat <b>Wildcat</b>
12. County <b>Chaves</b>

<p align="center"><b>SUNDRY NOTICES AND REPORTS ON WELLS</b> (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)</p>	
1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <b>Dry</b>	
2. Name of Operator <b>Murphy H. Baxter</b>	
3. Address of Operator <b>814 Southwest Building, Midland, Texas 79701</b>	
4. Location of Well UNIT LETTER <b>N</b> <b>660</b> FEET FROM THE <b>South</b> LINE AND <b>1980</b> FEET FROM THE <b>West</b> LINE, SECTION <b>7</b> TOWNSHIP <b>14 S</b> RANGE <b>30 E</b> NMPM.	
15. Elevation (Show whether DF, RT, GR, etc.) <b>3795 KB</b>	

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/> TEMPORARILY ABANDON <input type="checkbox"/> PULL OR ALTER CASING <input type="checkbox"/> OTHER <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/> CHANGE PLANS <input type="checkbox"/> OTHER <input type="checkbox"/>
	REMEDIAL WORK <input type="checkbox"/> COMMENCE DRILLING OPNS. <input type="checkbox"/> CASING TEST AND CEMENT JOB <input type="checkbox"/> OTHER <input type="checkbox"/>
	ALTERING CASING <input type="checkbox"/> PLUG AND ABANDONMENT <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Prepare to abandon well by cutting 4 1/2 casing, removing free casing, setting cement plug (25 sacks) in and above Queen perf (1964 to 1976). 25 sack plug in and out stub of 4 1/2 csg. 25 sack plug top of salt section. 25 sack plug at the bottom 8 5/8 (323') surface pipe. 10 sacks at surface. Mud - laden fluid to be used between plugs. Weld plate on surface pipe, w/4 ft. marker.

Estimated date 7/7/70

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.		
SIGNED <b>W. H. Summer</b>	TITLE <b>Manager</b>	DATE <b>7/2/70</b>
APPROVED BY <b>[Signature]</b>	TITLE <b>SUPERVISOR DISTRICT</b>	DATE <b>JUL 6 1970</b>
CONDITIONS OF APPROVAL, IF ANY:		

RECEIVED

JUL 6 1970

OIL CONSERVATION COMM.  
HOBBS, N. M.