

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
BUREAU OF LAND MANAGEMENT

**SUNDRY NOTICES AND REPORTS ON WELLS**

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.  
Use "APPLICATION FOR PERMIT—" for such proposals

**SUBMIT IN TRIPLICATE**

1. Type of Well  
☒ Oil Well ☐ Gas Well ☐ Other

2. Name of Operator

Read & Stevens, Inc.

3. Address and Telephone No.

P. O. Box 1518 Roswell, New Mexico 88202 505/622-3770

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

660' FNL & 660' FEL  
Section 20 T12S-R31E

FORM APPROVED  
Budget Bureau No. 1004-0135  
Expires: March 31, 1993

5. Lease Designation and Serial No.

NM-054926

6. If Indian, Allottee or Tribe Name

7. If Unit or CA, Agreement Designation

8. Well Name and No.

R&J Federal #1

9. API Well No.

30-005-20365

10. Field and Pool, or Exploratory Area

Chaves Queen Gas Area SE

11. County or Parish, State

Chaves County, New Mexico

12. CHECK APPROPRIATE BOX(S) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

- ☒ Notice of Intent  
☐ Subsequent Report  
☐ Final Abandonment Notice

TYPE OF ACTION

- ☐ Abandonment  
☐ Recompletion  
☐ Plugging Back  
☐ Casing Repair  
☐ Altering Casing  
☐ Other Plug and Abandon  
☐ Change of Plans  
☐ New Construction  
☐ Non-Routine Fracturing  
☐ Water Shut-Off  
☐ Conversion to Injection  
☐ Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)\*

Read & Stevens proposes to plug and abandon the subject well as follows:

- 1) Set CIBP @ 2,590' above Queen perforations 2,604'-09'. Spot 35' cmt plug on CIBP.  
2) Run tbg and set 100' cmt plug from 1,875'-1,775' across the top of the Yates. Free point 4 1/2" csg and shoot off and pull 4 1/2" csg from free point, anticipated to be approx. 1,500' from surface. Set 100' cmt plug across the top of the salt and anhydrite from 1,050' to 950'.  
3) Set 100' cmt plug from 50' below the base of the surface pipe to 50' above the base of the surface pipe. Surface pipe set @ 334'. *Tag plug.*  
4) Set ~~10~~ surface plug and cut off wellhead 3' below ground level. Install dry hole marker.  
5) Backfill and level location, install dry hole marker.

14. I hereby certify that the foregoing is true and correct

Signed John C. Moore, Jr.  
(This space for Federal or State office use)

Title Petroleum Engineer

Approved by \_\_\_\_\_  
Conditions of approval, if any:

Title \_\_\_\_\_

APPROVED 11-20-97  
PETER W. CHESTER  
DEC 2 1997

BUREAU OF LAND MANAGEMENT  
NATIONAL MONUMENT RESOURCE AREA

Title 18 U.S.C. Section 1001, makes it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

\*See Instruction on Reverse Side

OFFICE OF THE ATTORNEY GENERAL  
ROSWELL OFFICE

APR 25 10:10 AM

1961

APR 25 1961