

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER-	7. Unit Agreement Name
2. Name of Operator The Wil-Mc Oil Corporation	8. Farm or Lease Name Champlin State
3. Address of Operator Drawer 1889, Midland, Texas 79701	9. Well No. 1
4. Location of Well UNIT LETTER M, 660 FEET FROM THE West LINE AND 660 FEET FROM South, LINE, SECTION 3 TOWNSHIP 8S RANGE 33E NMPM.	10. Field and Pool, or Wildcat Chaveroo
15. Elevation (Show whether DF, RT, GR, etc.) 4408' Gr.	12. County Chaves

16.

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK	<input type="checkbox"/>
TEMPORARILY ABANDON	<input type="checkbox"/>
PULL OR ALTER CASING	<input type="checkbox"/>
OTHER	<input type="checkbox"/>

PLUG AND ABANDON	<input type="checkbox"/>
CHANGE PLANS	<input type="checkbox"/>
OTHER	<input type="checkbox"/>

SUBSEQUENT REPORT OF:

REMEDIAL WORK	<input type="checkbox"/>
COMMENCE DRILLING OPNS.	<input type="checkbox"/>
CASING TEST AND CEMENT JOB	<input type="checkbox"/>
OTHER	<input type="checkbox"/>
ALTERING CASING	<input type="checkbox"/>
PLUG AND ABANDONMENT	<input checked="" type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

- Set CIBP at 4100' and dumped 4 sacks cement on top of bridge plug.
- Shot off 4 1/2" casing at 1723', could not pull with 80,000 lbs. Shot off 4 1/2" at 1200' and pulled casing.
- Run tubing and displaced hole with 25 lbs./bbl. mud to 4 1/2" pipe stub at 1200'.
- Spotted 50 sacks cement over pipe stub at 1200'.
- Pulled tubing to 400' and displaced hole with mud.
- Spotted 50 sacks cement over surface pipe shoe at 400'.
- Finished displacing hole with mud and capped with 10 sacks cement.
- Installed marker, cleaned and leveled location.

Work completed 9-26-73

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>John K. Putnik</u>	TITLE <u>Engineer</u>	DATE <u>10-8-73</u>
APPROVED BY <u>John W. Remy</u>	TITLE <u>Asst</u>	DATE <u></u>
CONDITION OF APPROVAL, IF ANY:		