

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEYSUBMIT IN TRIPLICATE
(Other Instructions on
reverse side)Form approved.
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

NM 18508

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Luther-A

9. WELL NO.

1

10. FIELD AND POOL, OR WILDCAT

Lonesome San Andres

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA

18, 8-S, 32-E

12. COUNTY OR PARISH

Chaves

13. STATE

New Mexico

1. OIL WELL ☒ GAS WELL ☐ OTHER

2. NAME OF OPERATOR

Phillips Petroleum Company

3. ADDRESS OF OPERATOR

Room 711, Phillips Bldg., Odessa, Texas 79761

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*
See also space 17 below.)
At surface

(Unit N) 660' FS and 1980' FW lines

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

4395.2' Gr.

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETION

ABANDON*

CHANGE PLANS

X

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

(Note: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Prepare plug and abandon as follows:

1. Pull rods and pump.
2. Load hole with mud mixed 25 sacks salt gel per 100 barrels brine or produced water.
3. Spot 200 sx Class H cement from approximately 4720' to 4030'.
4. Cut and pull 8-5/8" csg at freepoint. (top of cement at approximately 2000')
5. Spot 50 sx Class H cement across 8-5/8" casing cut (cmt from 50' below cut to 50' above cut.)
6. Spot 100 sx Class H cement across 13-3/8" csg shoe at 427' (approximately 500' to 300').
7. Spot 10 sx Class H cement in 13-3/8" csg at surface.
8. Install well marker.
9. Fill and level pits, clear location.

Field Representative: E. T. Millholon, telephone 393-3664.

18. I hereby certify that the foregoing is true and correct

SIGNED

W. J. Mueller

TITLE

Engineering Advisor

DATE


12-2-75

(This space for Federal or State office use)

APPROVED BY

CONDITIONS OF APPROVAL, IF ANY:

TITLE



*See Instructions on Reverse Side