

NO. OF COPIES RECEIVED

DISTRIBUTION

SANTA FE

FILE

U.S.G.S.

LAND OFFICE

OPERATOR

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease

State ☒Fee ☐

5. State Oil & Gas Lease No.

B-10416

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>		7. Unit Agreement Name
2. Name of Operator James P. Graham		8. Farm or Lease Name Graham et al
3. Address of Operator 4223 Emerson - Dallas, Texas 75205		9. Well No. #1
4. Location of Well UNIT LETTER <u>I</u> , <u>1340</u> FEET FROM THE <u>South</u> LINE AND <u>1300</u> FEET FROM THE <u>East</u> LINE, SECTION <u>12</u> TOWNSHIP <u>135</u> RANGE <u>31E</u> NMPM.		10. Field and Pool, or Wildcat Caprock Queen
15. Elevation (Show whether DF, RT, GR, etc.) 4398' GL		12. County Chaves

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input checked="" type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Move in, rig up
2. Pull rods and pump
3. Pull tubing
4. Run 4 1/2" Bridge Plug and set at 2850', dump 3 sacks cement on top
5. Load hole w/mud
6. Cut 4 1/2" @ 1110' and pull casing
7. Run tubing and set 100' plug @ 1110'
8. Set 100' plug @ 321'
9. 10 sack cement plug at surface
10. Mud between and displcaed w/mud
11. Rig down, install dry hole marker and level location.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED

TITLE

Agent

DATE June 28, 1976

APPROVED BY

TITLE

Geologist

DATE

JUL 12 1976

CONDITIONS OF APPROVAL, IF ANY:

RECEIVED

JUN 29 1976

OIL CONSERVATION COMM.
HOBBS, N. M.