

Submit 3 Copies

State of New Mexico

Form C-103

District Office

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION

P.O. Box 2088
Santa Fe, New Mexico 87504-2088

WELL API NO.

30-005-20543

5. Indicate Type of Lease

STATE ☒

FEE ☐

6. State Oil & Gas Lease No.

LG-1520

7. Lease Name or Unit Agreement Name

Cone State

8. Well No.

1

9. Pool name or Wildcat

Tom Tom San Andres

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well:

OIL WELL ☒

GAS WELL ☐

OTHER

2. Name of Operator

YATES PETROLEUM CORPORATION

3. Address of Operator

105 South 4th St., Artesia, NM 88210

4. Well Location

Unit Letter H : 1980 Feet From The North Line and 660 Feet From The East Line

Section 2

Township 8S

Range 31E

NMPM

Chaves

County

10. Elevation (Show whether DF, RKB, RT, GR, etc.)

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐

PLUG AND ABANDON ☒

TEMPORARILY ABANDON ☐

CHANGE PLANS ☐

PULL OR ALTER CASING ☐

OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐

ALTERING CASING ☐

COMMENCE DRILLING OPNS. ☐

PLUG AND ABANDONMENT ☐

CASING TEST AND CEMENT JOB ☐

OTHER: ☐

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Propose to plug and abandon as follows:

1. Pump water as needed to nipple down wellhead. POOH with rods. Nipple up BOP. TOOH with tubing.

2. Wireline run gauge ring to 3930'. TOOH with gauge ring. TIH with CIBP and set CIBP at 3930'. Cap CIBP with 35' of cement.

3. TIH with tubing and tag CIBP. Load casing with 10# brine gel mud. TOOH with tubing.

4. Nipple down BOP and nipple down wellhead. Make up landing joint on 4-1/2" casing. Pick up on casing and wireline cut casing at 3000'. TOOH with casing.

5. TIH with 2-3/8" mule shoed open ended tubing. Set a 35 sack Class C cement plug from 50' below casing cut to 50' above. Use 2% CaCl2 (BWOC). WOC 2 hours. Tag plug.

6. Set a 35 sack Class C cement plug from 1615-1515'.

7. Set a 35 sack Class C cement plug from 1200-1100'.

8. Set a 10 sack Class C cement plug at surface.

9. Install regulation abandonment marker.

I hereby certify that the information above is true and complete to the best of my knowledge and belief. 24 HOURS PRIOR TO COMMENCING PLUGGING OPERATIONS

SIGNATURE Rusty Klein TITLE Operations Technician DATE July 29, 1999

TYPE OR PRINT NAME Rusty Klein

TELEPHONE NO. 505/748-1471

(This space for State Official)

ORIGINAL SIGNED BY

GARY WINK

APPROVED BY

FIELD REP. II

TITLE

DATE

AUG 04 1999

CONDITIONS OF APPROVAL, IF ANY: