

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEYSUBMIT IN TRIPLICATE
(Other instructions on
reverse side)Form approved.
Budget Bureau No. 42-R1424.
5. LEASE DESIGNATION AND SERIAL NO.

NM 15892

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Hudson Federal

9. WELL NO.

10. FIELD AND POOL, OR WILDCAT

Wildcat

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA

Sec. 7, T7S-R31 E

12. COUNTY OR PARISH 13. STATE

Chaves

NM

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1.

OIL WELL ☒ GAS WELL ☐ OTHER

2. NAME OF OPERATOR

Blair Exploration Inc. & Thomas R. Metcalfe

3. ADDRESS OF OPERATOR

308 HBF Building, Midland, Texas 79701

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*
See also space 17 below.)
At surface

660' FSL & 660' FEL

Unit "P"

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

4322 GL

16.

Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

PULL OR ALTER CASING

FRACTURE TREAT

MULTIPLE COMPLETE

SHOOT OR ACIDIZE

ABANDON*

REPAIR WELL

CHANGE PLANS

(Other)

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

REPAIRING WELL

FRACTURE TREATMENT

ALTERING CASING

SHOOTING OR ACIDIZING

ABANDONMENT*

(Other)

(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

1. Run tbg. to 4800' and circulate hole with 10# mud laden fluid using 25 sacks of salt gel with 100 bbls. of brine water.
2. Spotted a 25 sack plug at 4800' and tagged plug at 3550'.
3. Shot 4-1/2" csg. at 1700' - pulled & layed down 4-1/2" csg.
4. Run tbg. to 1750' and pump & spot a 25 sack plug from 1750' to 1650'.
5. Pulled tbg. to 1400' & spotted a 30 sack plug from 1400' to 1300'.
6. Pulled tbg. to 450' & spotted a 30 sack plug from 450' to 350'.
7. POH - cut off well head, install Dry Hole marker and surface plug. Rigged down.

18. I hereby certify that the foregoing is true and correct

SIGNED

TITLE

P.H.A. Cont.

DATE

10-4-77

(This space for Federal or State office use)

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY: