

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease  
State ☐ Fee ☒

5. State Oil & Gas Lease No.  
202706

## SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator Flag-Redfern Oil Company	8. Farm or Lease Name Wilson
3. Address of Operator P. O. Box 23 Midland, TX 79702	9. Well No. 1
4. Location of Well UNIT LETTER <u>A</u> <u>660</u> FEET FROM THE <u>North</u> LINE AND <u>660</u> FEET FROM THE <u>East</u> LINE, SECTION <u>31</u> TOWNSHIP <u>8-S</u> RANGE <u>32-E</u> NMPM.	10. Field and Pool, or Wildcat Undesignated (SA)
15. Elevation (Show whether DF, RT, GR, etc.) 4399' G. L.	12. County Chaves

## Check Appropriate Box To Indicate Nature of Notice, Report or Other Data NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

## 17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

- Run 2-3/8" tubing to 4094' (Top San Andres Perforation).
- Displace 4-1/2" casing with 9.5 lb/gal mud laden fluid.
- Spot 100' cement plug from 4094' to 3094 using 15 sx. of Class "A" cement.
- Pull up tubing to 1657' (opposite 4-1/2" stage cementing tool).
- Spot 100' cement plug from 1657' to 1557' using 15 sx. of Class "A" cement.
- Pull tubing out of hole.
- Place a 10 sx. cement plug inside the 4-1/2" casing at the surface.
- Cut off the 4-1/2" and 8-5/8" casing strings below ground level and weld a steel plate over the same.
- Weld a permanently engraved 4-1/2" O.D. X 6' dry hole marker on top the steel plate over the casings strings.
- Clean location and cover up pits.

Commencement of Plugging operations will be upon receipt of approved permit.

THE COMMISSION MUST BE NOTIFIED 24 HOURS PRIOR TO THE START OF PLUGGING OPERATIONS AND MUST BE APPROVED.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED [Signature] TITLE Petroleum Engineer DATE July 6, 1978

Orig. Signed by

Jerry Barton

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY:

Ex. filed 1/16/79

JUL 10 1978