

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
GEOLOGICAL SURVEYSUBMIT IN TRIPLICATE  
(Other instructions on reverse side)Form approved.  
Budget Bureau No. 42-R1424.

## SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.  
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>		5. LEASE DESIGNATION AND SERIAL NO. N.M. 15677A	
2. NAME OF OPERATOR Exxon Corporation		6. IF INDIAN, ALIOTTEE OR TRIBE NAME --	
3. ADDRESS OF OPERATOR P. O.Box 1600, Midland, Texas 79702		7. UNIT AGREEMENT NAME --	
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See also space 17 below.) At surface  1980' FSL and 660' FEL of Section		8. FARM OR LEASE NAME Strange Federal	
14. PERMIT NO.		9. WELL NO. 4	
15. ELEVATIONS (Show whether DF, RT, GR, etc.) Gr. 4406.5		10. FIELD AND POOL, OR WILDCAT Tomahawk San Andres	
		11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA Sec. 25, T7S, R31E	
		12. COUNTY OR PARISH Chaves	13. STATE New Mexico

## 16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

## NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐FRACTURE TREAT ☐SHOOT OR ACIDIZE ☐REPAIR WELL ☐(Other) Change to drilling program ☐PULL OR ALTER CASING ☐MULTIPLE COMPLETE ☐ABANDON\* ☐CHANGE PLANS ☐

## SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐FRACTURE TREATMENT ☐SHOOTING OR ACIDIZING ☐(Other) ☐REPAIRING WELL ☐ALTERING CASING ☐ABANDONMENT\* ☐

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)\*

1. 8 5/8" surf. casing setting depth 400'  
Quantity of cement = 500 cu. ft.

## 2. Explanation:

Surface casing will be set at approximately 400' to protect fresh water zones.  
Production casing will be cemented to surface (A stage cementing tool will be used if necessary).

Mud Program      0- 400' fresh water spud mud  
                    400-3200' Brine Water 10#  
                    3200-TD Brine water and starch 10#

RECEIVED

NOV 30 1979

U.S. GEOLOGICAL SURVEY  
ARTESIA, NEW MEXICO

18. I hereby certify that the foregoing is true and correct

SIGNED

Ed Rumbel

TITLE Proration Specialist

DATE 11-29-79

(This space for Federal or State office use)  
(C.E.S.)APPROVED BY GEORGE H. STEWART

TITLE ACTING DISTRICT ENGINEER

DATE NOV 30 1979

CONDITIONS OF APPROVAL, IF ANY: