

STATE OF NEW MEXICO  
ENERGY AND MINERALS DEPARTMENT

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

OIL CONSERVATION DIVISION

P. O. BOX 2088  
SANTA FE, NEW MEXICO 87501

Form C-103  
Revised 10-1-78

5a. Indicate Type of Lease  
State ☐ Fee ☒

5. State Oil & Gas Lease No.  
18756

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>		7. Unit Agreement Name NA
2. Name of Operator Adams Exploration Company		8. Farm or Lease Name Hooper
3. Address of Operator P. O. Box 10585 Midland, Texas 79702		9. Well No. 2
4. Location of Well UNIT LETTER H 1980 FEET FROM THE North LINE AND 660 FEET FROM East LINE, SECTION 10 TOWNSHIP 8S RANGE 32E N.M.P.M.		10. Field and Pool, or Wildcat Chaveroo (San Andres)
15. Elevation (Show whether DF, RT, GR, etc.) 4462 GR		12. County Chaves

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input checked="" type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1703.

3-20-82 MIRU DA & S Pulling Unit. Pulled rods and pump. SDON  
3-21-81 SD for Sunday  
3-22-82 POOH with 135 jts. 2 3/8" 4.7# J-55 EUE 8rd tbg. Pick up 4 1/2" CIBP and GIH to 4130' and set CIBP. Circulated hole with 10# mud and spot 5 sx Class "C" cement. POOH with tubing and SDON.  
3-23-82 RU to pull casing. RU Energy Wireline free pt, and shoot off casing at 3250'. POOH laying down 1500' of 4 1/2" 10.5# casing. SDON.  
3-24-82 Finish POOH with 4 1/2" 10.5# casing (Total 80 jts.) 3250'. GIH with tubing and set 35 sx cement plug and POOH with tubing. SDON.  
3-25-82 GIH with tubing and tag TOC at 3114'. POOH with tubing pickup an 8 5/8" CIBP and GIH and set at 1810'. Spot 5 sx. Class "C" Cement Plug and POOH laying down tubing. SDON.  
3-26-82 Spot a 10 sx Class "C" plug at the surface, cut-off the head and on a plate and install dry hole marker. These operations were directed by Mr. Tony Platsmire with NMOCD. Well Plug & Abandoned.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED J. M. Reeves J. M. Reeves TITLE Drllg. & Production Engineer DATE April 1, 1982

APPROVED BY Eddie W. Dean TITLE OIL & GAS INSPECTOR DATE APR 15 1982

CONDITIONS OF APPROVAL, IF ANY:

**RECEIVED**

APR 5 1982

**O.C.D.  
HOBBS OFFICE**