

UNITED STATES N. M. OIL & GAS
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT
HOBBS, NEW MEXICO 88240

Form approved.
Budget Bureau No. 1004-(13)
Expires August 31, 1985

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)


1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. UNIT AGREEMENT NAME
2. NAME OF OPERATOR	8. FARM OR LEASE NAME
3. ADDRESS OF OPERATOR	9. WELL NO.
Western Reserves Oil Co.	Western Reserves "34" Federal
P.O. Box 993, Midland, Texas 79702	6
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See also space 17 below.) At surface	10. FIELD AND POOL, OR WILDCAT
Unit K, 1980' FSL & 1980' FWL	Tom-Tom (San Andres)
14. PERMIT NO.	11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA
15. ELEVATIONS (Show whether DF, RT, GR, etc.)	Sec 34, T7S-R31E
4350 GR	12. COUNTY OR PARISH
	Chaves
	13. STATE
	NM

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
TEST WATER SHUT-OFF <input type="checkbox"/>	PULL OR ALTER CASING <input type="checkbox"/>	WATER SHUT-OFF <input type="checkbox"/>	REPAIRING WELL <input type="checkbox"/>
FRACTURE TREAT <input type="checkbox"/>	MULTIPLE COMPLETE <input type="checkbox"/>	FRACTURE TREATMENT <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
SHOOT OR ACIDIZE <input type="checkbox"/>	ABANDON* <input checked="" type="checkbox"/>	SHOOTING OR ACIDIZING <input type="checkbox"/>	ABANDONMENT* <input type="checkbox"/>
REPAIR WELL <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	(Other) <input type="checkbox"/>	
(Other) <input type="checkbox"/>		(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)	

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

SEE ATTACHED PLUGGING PROPOSAL



18. I hereby certify that the foregoing is true and correct

SIGNED Peter W. Chester TITLE Agent DATE 2-21-89

(This space for Federal or State office use)


APPROVED BY _____
CONDITIONS OF APPROVAL, IF ANY:

TITLE _____

DATE APPROVED
PETER W. CHESTER

MAR 1 1989

*See Instructions on Reverse Side



Natural Resources Engineering

PLUGGING PROPOSAL

OPERATOR: WESTERN RESERVES OIL CO. INC.

WELL: WESTERN RESERVES "34" FEDERAL #6

FIELD: TOM-TOM (SAN ANDRES)

LOCATION: SECTION 34, T7S-R31E

COUNTY: CHAVES

STATE: NEW MEXICO

TOTAL DEPTH: 3975'

DATE: FEBRUARY 21, 1989

REV: 0

1. Rig up well plugging unit, pull and lay down rods and pump.
2. Pull 2 3/8" tubing and stand in derrick.
3. Rig up wireline and run in hole with gauge ring to 3790'±.
4. Set CIBP on wireline @ 3775'±, cap w/ ~~2 3/8"~~ cement. *{ 35' cmt. w/ dump bailer
50' cmt through tubing }*
5. Rig up and take stretch on 4 1/2" 10.5# K-55 ST&C csg. Should be free about 2800'.
6. Shot off csg and pull same. Run back to 3760'± with tubing, displace hole with Salt Gel Mud.
7. Set a 35 sx plug across 4 1/2" csg stub @ 2800'. Tag this plug.
8. Set ⁴³~~35~~ sx plug @ 1450-1550' across 8 5/8" csg shoe @ 1495'. *tag plug.*
9. Set ¹⁸~~18~~ sx plug @ surface. Remove wellhead. Weld cap on 8 5/8" csg, install dry hole marker. Rig down plugging unit, cut off anchors, clean location and release unit.
10. Remove all equipment and clean location, prepare for inspection.

WP/plugwroc.txt

