

STATE OF NEW MEXICO
ENERGY AND MINERALS DEPARTMENT

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.O.S.	
LAND OFFICE	
OPERATOR	

OIL CONSERVATION DIVISION
P. O. BOX 2088
SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-78

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. <input checked="" type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER		5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
2. Name of Operator Siete Oil & Gas Corporation		5. State Oil & Gas Lease No. LG 1397
3. Address of Operator P. O. Box 2523 Roswell, New Mexico 88202		7. Unit Agreement Name
4. Location of Well UNIT LETTER <u>H</u> <u>1980</u> FEET FROM THE <u>North</u> LINE AND <u>660</u> FEET FROM THE <u>East</u> LINE, SECTION <u>4</u> TOWNSHIP <u>8</u> South RANGE <u>32</u> East N.M.P.M.		8. Farm or Lease Name Chaveroo State
		9. Well No. 1
		10. Field and Pool, or Wildcat Chaveroo-San Andres
15. Elevation (Show whether DF, RT, GR, etc.) 4507'		12. County Chaves

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>

SUBSEQUENT REPORT OF:

REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Perfs - 4225' to 4252' (26 shots)

4291' to 4362.5' (32 shots)

PROCEDURE:

1. TOH w/ rods and tubing
2. Set Cast Iron Bridge Plug @ 4214' + - & Dump 35' cement on CIBP
3. Perforate @ 1809'
4. Load hole w/10# salt gel
5. Set 25 sk. plug @ 3000'
6. Pull TBG to 1809' - Break circulation & spot 75 sk. plug ½ inside and ½ outside of 4½" casing
7. Set 10 sk. plug in top of 4½" casing.

THE OPERATOR MUST BE NOTIFIED 24 HOURS BEFORE THE BEGINNING OF OPERATIONS FOR THE C-103 TO BE APPROVED.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED D. Juster TITLE V.P. Drilling & Production DATE October 20, 1987

ORIGINAL SIGNED BY JERRY SEXTON

APPROVED BY DISTRICT 1 SUPERVISOR TITLE DATE OCT 22 1987

CONDITIONS OF APPROVAL, IF ANY: