


5-18-87

1. MIRU completion unit. TOH LD rods and pump.
2. TIH to 3980'± (SN now at 3951'). Load hole with fresh water. Spot 35 sx premium plus cement from 3980' to 3464'. POH to 3000'. Reverse circulate clean. WOC 3 hrs. TIH and tag top of plug (Must have a minimum of 50' above perforations). Circulate hole with mud laden fluid (9.5 lb/gal. Mix a minimum of 25 sx (50 lbs each) of gel per 100 bbls of water) TOH.
3. Pull stretch on 4 1/2" casing to determine freepoint. Shoot casing off just above freepoint. TOH LD 4 1/2" casing.
4. TIH with 2 3/8" tubing 50' inside casing stub. Spot 25 sx premium plus containing 2% CaCl. (WOC and tag if required by BLM) *Tag plug.*
5. POH to 1615'. Spot 30 sx premium plus from 1615' to 1498'. *P.W.C.*
6. TOH LD tubing
7. Spot 15 sx premium plus from 50' to surface.
8. Cut casing off. Install dry hole marker. Marker to have minimum diameter of 4" and extend 4' above ground level. The following to be welded on marker:
 - A. Flag-Redfern Oil Company
 - B. Rutter 26 Federal No. 1
 - C. Sec. 26, T-8-S, R-31-E
 - D. 1980' FSL and 1980' FEL
 - E. Lease No. NM-64502
9. Clean location.



RECEIVED

1967 JUN 14
10:00 AM
100-100000-100000