

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.
7. Unit Agreement Name No. 1 No. Caprock Queen Unit
8. Farm or Lease Name No. Caprock Queen Unit
9. Well No. Tract 17, Well No. 5
10. Field and Pool, or Wildcat Caprock Queen (Lea)
12. County Lea

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)	
1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <input type="checkbox"/>	
2. Name of Operator Thunderbird Oil Corporation	
3. Address of Operator P. O. Box 1778, Midland, Texas 79701	
4. Location of Well UNIT LETTER <u>E</u> , <u>1980</u> FEET FROM THE <u>North</u> LINE AND <u>660</u> FEET FROM THE <u>West</u> LINE, SECTION <u>6</u> TOWNSHIP <u>13-S</u> RANGE <u>32-E</u> NMPM.	
15. Elevation (Show whether DF, RT, GR, etc.) 4380' GL	

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

8-5/8" @ 300' w/160 sx.
5-1/2" @ 3034' w/300 sx.

1. Displace hole with 2500# per 100 bbls. salt base mud.
2. Set CIBP @ approximately 2950'.
3. Set 35' cement plug (5 sx.) on top of CIBP.
4. Cut off and pull 5-1/2" casing at approximately 1000'.
5. Spot 35 sx. cement plug in-and-out of 5-1/2" casing stub.
6. Spot 35 sx. cement plug in-and-out of 8-5/8" casing stub.
7. Spot 10 sx. cement plug at surface and erect a 4 1/2" regulation dry hole marker.
8. Clean up location for NMOCC inspection and approval.

160' plugs

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.			
SIGNED <u>Harry F. Schram</u>	TITLE <u>President</u>	DATE <u>Feb. 26, 1975</u>	
APPROVED BY _____	TITLE _____	DATE _____	
CONDITIONS OF APPROVAL, IF ANY:			