

| | |
|------------------------|--|
| NO. OF COPIES RECEIVED | |
| DISTRIBUTION | |
| SANTA FE | |
| FILE | |
| U.S.G.S. | |
| LAND OFFICE | |
| OPERATOR | |

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

| | |
|---|------------------------------|
| 5a. Indicate Type of Lease | |
| State <input checked="" type="checkbox"/> | Fee <input type="checkbox"/> |
| 5. State Oil & Gas Lease No. | |
| 7. Unit Agreement Name No. 1 | |
| No. Caprock Queen Unit | |
| 8. Farm or Lease Name | |
| No. Caprock Queen Unit | |
| 9. Well No. | |
| Tract 22, Well No. 12 | |
| 10. Field and Pool, or Wildcat | |
| Caprock Queen (Lea) | |
| 12. County | |
| Lea | |

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

| | | |
|---|-----------------------------------|-----------------------|
| 1. OIL WELL <input type="checkbox"/> | GAS WELL <input type="checkbox"/> | OTHER- Injection Well |
| 2. Name of Operator | | |
| Thunderbird Oil Corporation | | |
| 3. Address of Operator | | |
| P. O. Box 1778, Midland, Texas 79701 | | |
| 4. Location of Well | | |
| UNIT LETTER L 1980 FEET FROM THE South LINE AND 660 FEET FROM THE West LINE, SECTION 6 TOWNSHIP 13-S RANGE 32-E NMPM. | | |

15. Elevation (Show whether DF, RT, GR, etc.)

4386' GL

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐
TEMPORARILY ABANDON ☐
PULL OR ALTER CASING ☐
OTHER ☐

PLUG AND ABANDON ☒
CHANGE PLANS ☐
OTHER ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐
COMMENCE DRILLING OPNS. ☐
CASING TEST AND CEMENT JOB ☐
OTHER ☐
ALTERING CASING ☐
PLUG AND ABANDONMENT ☐

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

8-5/8" @ 255' w/125 sx.
5-1/2" @ 3007' w/600 sx.
4-1/2" Liner @ 2991-3021'.

1. Displace hole with 2500# per 100 bbls. salt base mud.
2. Set CIBP @ approximately 2900'.
3. Set 35' cement plug (5 sx.) on top of CIBP.
4. Cut off and pull 5-1/2" casing at approximately 1000'.
5. Spot 35 sx. cement plug in-and-out of 5-1/2" casing stub.
6. Spot 35 sx. cement plug in-and-out of 8-5/8" casing stub.
7. Spot 10 sx. cement plug at surface and erect a 4 1/2" regulation dry hole marker.
8. Clean up location for NMOCC inspection and approval.

100' plugs

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Kenny F. Schuman TITLE President DATE Feb. 26, 1975

APPROVED BY _____ TITLE _____ DATE _____
CONDITIONS OF APPROVAL, IF ANY:

RECEIVED

APR 1 1973

U. S. CONGRESS
LIBRARY