## State of New Mexico Energy, linerals and Natural Resources Department

Form C-103 Revised 1-1-89

DISTRICT I P.O. Box 1980, Hobbs, NM 88240

DISTRICT II P.O. Drawer DD, Artesia, NM 88210

OIL CONSERVATION DIVISION P.O. Box 2088

Santa Fe, New Mexico 87504-2088

WELL API NO. 30-025-01059

5. Indicate Type of Lease

DISTRICT III	STATE X FEE
1000 Rio Brazos Rd., Aziec, NM 87410	6. State Oil & Gas Lease No. B-9473
SUNDRY NOTICES AND REPORTS ON WELLS	
( DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A	7. Lease Name or Unit Agreement Name
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT"  (FORM C-101) FOR SUCH PROPOSALS.)	7. Louis rane of our Agreement ranse
1. Type of Well:	-
OIL GAS WELL X OTHER	Hope State
2. Name of Operator	8. Well No.
Kaiser-Francis Oil Company	1.
3. Address of Operator	9. Pool name or Wildcat
P. O. Box 21468, Tulsa, OK 74121-1468	Hightower Permo Penn
4. Well Location	
Unit Letter $\frac{P}{}: \underline{660}$ Feet From The $$ South $$ Line and $$ 66	60 Feet From The East Line
	- 11 - 11 - 11 - 11 - 11 - 11 - 11 - 1
	NMPM Lea County
10. Elevation (Show whether DF, RKB, RT, GR, etc.)	n/a
11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data	
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:	
ERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORK	
	ALTERING CASING
EMPORARILY ABANDON	GOPNS. PLUG AND ABANDONMENT
ULL OR ALTER CASING CASING TEST AND CE	EMENT JOB .
OTHER: OTHER:	·
12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed	
work) SEE RULE 1103.	
1. MIRU WSU. TOOH w/tbg.	Additional files
2. Set CIBP @ 8360' w/35' cmt on top.	AT Alun 6) EIGO
3. Run tbg to 8315' & circ hole w/9.5# SW gel.	
4. Cut & pull estimated 4000' of 7" casing.	
work) SEE RULE 1103.  1. MIRU WSU. TOOH w/tbg.  2. Set CIBP @ 8360' w/35' cmt on top.  3. Run tbg to 8315' & circ hole w/9.5# SW gel.  4. Cut & pull estimated 4000' of 7" casing.  5. Set 60 sx cmt plug 50' in & 50' out of casing stub.  6. Set 75 sx cmt plug @ 3930'-3830'.	
6. Set 75 sx cmt plug @ 3930'-3830'.	
7. Set 75 sx cmt plug @ 360'-260'.	
8. Set 15 sx cmt plug @ 30' to surface.	
9. Cut off casing & install DH marker.	
Anticipated starting date: 5/25/01.	

IC

TYPE OR PRINT NAME

(This space for State Use)

CONDITIONS OF AFFROVAL, IF ANY:

APPROVED BY --

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

Charlotte Van Valkenburg

DATE 4/19/01

TELEPHONE NO.

- DATE

Technical Coordinator

918-491-4314

