

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

OIL CONSERVATION DIVISION
P. O. BOX 2088
SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-78

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	
B10083	
7. Unit Agreement Name	
8. Farm or Lease Name	
State BT "E"	
9. Well No.	
1	
10. Field and Pool, or Wildcat	
Hightower Devonian	
12. County	
Lea	

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- TA'd
2. Name of Operator
Amerada Hess Corporation
3. Address of Operator
Drawer D, Monument, New Mexico 88265
4. Location of Well
UNIT LETTER N , 660 FEET FROM THE South LINE AND 1980 FEET FROM THE West LINE, SECTION 23 TOWNSHIP 12S RANGE 33E NMPM.

15. Elevation (Show whether DF, RT, GR, etc.)
4632' DF

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>
OTHER <input type="checkbox"/>	OTHER <input type="checkbox"/>
PLUG AND ABANDON <input checked="" type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
CHANGE PLANS <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1703.

Plan to MIRU pulling unit & TOH w/production eqpt. TIH w/5-½" CIBP on wireline set at 9974' TIH w/2-7/8" workstring & circ. hole w/mud. Spot 100' cement plug across top of Devonian zone fr. 9974'-9874'. Pull up hole & spot 100' plug across top of Wolfcamp zone fr. 8470'-8370'. RU casing crew, TIH w/casing cutters & cut 5-½" csg. at approx. 6500'. TOH laying down 5-½" csg. Spot 100' cement plug across 5½' csg. cut. (50' above cut & 50' below cut.) Pull up hole & spot 100' cement plug across base of San Andres zone fr. 5118'-5018'. Pull up hole & spot 100' cement plug across intermediate csg. shoe fr. 3970'-3870'. Perforate 8-5/8" csg. at 307'. Pump 50 sks. outside of perf. at 307' & leave 20 sks. inside of csg. Spot 10 sk. cement plug at surface, remove wellhead, install dry hole marker & clean location.

ALL OPERATIONS MUST BE NOTIFIED 24 HOURS PRIOR TO THE BEGINNING OF PLUGGING OPERATIONS FOR THE CH03 TO BE APPROVED.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED R. L. Wheeler, Jr. TITLE Supv. Adm. Svc. DATE 5-27-88

APPROVED BY _____ TITLE OIL & GAS INSPECTOR DATE MAY 31 1988

CONDITIONS OF APPROVAL, IF ANY: