

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION
P.O. Box 2088
Santa Fe, New Mexico 87504-2088

WELL API NO. 30-25-01120
5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No. E-7353
7. Lease Name or Unit Agreement Name A Lion State
8. Well No. #2
9. Pool name or Wildcat Saunders Permo (Upper Penn)

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well: OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	2. Name of Operator Eclipse Oil & Gas, Inc.
3. Address of Operator P.O. Box 15122 Odessa, TX 79768	4. Well Location Unit Letter P : 660 Feet From The South Line and 660 Feet From The East Line Section 9 Township 14S Range 33E NMPM Lea County
10. Elevation (Show whether DF, RKB, RT, GR, etc.) 4224 GR.	

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
OTHER: <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
	CASING TEST AND CEMENT JOB <input type="checkbox"/>
	OTHER: <input type="checkbox"/>

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.
(NOTIFY CONSERVATION COMMISSION (505) 393-6161 24HRS BEFORE OPERATIONS BEGIN.)

(1) MIRU Unit, test tbq. to 500#, POH w/rods and tbq.
(2) Set CIBP on WL @ 9750' and cap w/3sx. cmt. 35' w/DUMPBAILER OR 25SX - TAG BOTTOM PLUG
(3) TIH w/tbg., circ hole w/10# BW w/25# SWG per bbl. pump 25sx. plug @ 7000', POH w/tbg.
(4) Stretch, cut and lay down 5-1/2" csg.
(5) TIH w/tbg. Pump 50' in & 50' out plug across 5 1/2" stub. (TAG W/Tbg.)
(6) Pump 100' plug across 8-5/8" shoe @ 4153'. (TAG W/TBG.)
(7) POH w/tbg., stretch cut and lay down 8-5/8" csg.
(8) TIH w/tbg., Pump 50' in & 50' out plug across 8-5/8" stub. (TAG W/TBG.)
(9) Pump 100' plug across 13-3/8" shoe @ 367'. (TAG W/TBG.)
(10) Pump 15sx. surface plug.
(11) Install dry hole marker.

→ NEED SALT PLUG F/1795' to 1695'

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE <i>Frelan Fields</i>	TITLE Agent	DATE 9/18/00
TYPE OR PRINT NAME Frelan Fields		(915) 366-1852
		TELEPHONE NO.

(This space for State Use)

APPROVED BY	TITLE	DATE
CONDITIONS OF APPROVAL, IF ANY:		

SEP 28 2000

