

Submit 3 Copies  
to Appropriate  
District Office

State of New Mexico  
Energy, Minerals and Natural Resources Department

Form C-103  
Revised 1-1-89

DISTRICT I  
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II  
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III  
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION  
P.O. Box 2088  
Santa Fe, New Mexico 87504-2088

WELL API NO. 203-025-01165
5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No. E-2114
7. Lease Name or Unit Agreement Name State H
8. Well No. 4
9. Pool name or Wildcat Saunders Permian Upper Penn.

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)	
1. Type of Well: OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	
2. Name of Operator CHARLES B. GILLESPIE, JR.	
3. Address of Operator P.O. BOX 8 Midland, Tx. 79702	
4. Well Location Unit Letter <u>0</u> : <u>660</u> Feet From The <u>south</u> Line and <u>1980</u> Feet From The <u>east</u> Line Section <u>28</u> Township <u>14-S</u> Range <u>33-E</u> NMPM <u>Lea</u> County <u></u>	
10. Elevation (Show whether DF, RKB, RT, GR, etc.)	

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data  
NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☐  
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐  
PULL OR ALTER CASING ☐  
OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐  
COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☒  
CASING TEST AND CEMENT JOB ☐  
OTHER: ☐

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

- (1) A CIBP was set in 1986 @9750', cap w/35' cement
- (2) Load hole w/mud
- (3) Spot 25 sacks cement @ 6500'
- (4) Spot 50 sacks cement @4200', to cover 8 5/8 shot, 5 1/2 liner, top W.O.C. tag cement @ 2960', spot 25 sacks cement to bring cement plug up higher W.O.C. Tag cement top @3907'
- (5) Perforate 8 5/8 casing @ 370', squeeze 70 sacks cement, W.O.C. did not tag plug. Spot 60 sacks cement across perforation, casing held pressure at 500 psi
- (6) spot 15 sacks cement to surface & set P&A marker

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Raymond Maldonado

TITLE Supervisor

DATE 11-20-93

TYPE OR PRINT NAME

TELEPHONE NO.

(This space for State Use)

APPROVED BY Jack Griffin

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY: