

NEW MEXICO OIL CONSERVATION COMMISSION

Santa Fe, New Mexico

MISCELLANEOUS NOTICES

Submit this notice in TRIPLICATE to the District Office, Oil Conservation Commission, before the work specified is to begin. A copy will be returned to the sender on which will be given the approval, with any modifications considered advisable, or the rejection by the Commission or agent, of the plan submitted. The plan as approved should be followed, and work should not begin until approval is obtained. See additional instructions in the Rules and Regulations of the Commission.

Indicate Nature of Notice by Checking Below

NOTICE OF INTENTION TO CHANGE PLANS		NOTICE OF INTENTION TO TEMPORARILY ABANDON WELL		NOTICE OF INTENTION TO DRILL DEEPER	
NOTICE OF INTENTION TO PLUG WELL	<input checked="" type="checkbox"/>	NOTICE OF INTENTION TO PLUG BACK		NOTICE OF INTENTION TO SET LINER	
NOTICE OF INTENTION TO SQUEEZE		NOTICE OF INTENTION TO ACIDIZE		NOTICE OF INTENTION TO SHOOT (Nitro)	
NOTICE OF INTENTION TO GUN PERFORATE		NOTICE OF INTENTION (OTHER)		NOTICE OF INTENTION (OTHER)	

OIL CONSERVATION COMMISSION
SANTA FE, NEW MEXICO

Hobbs, New Mexico
(Place)

March 18, 1953
(Date)

Gentlemen:

Following is a Notice of Intention to do certain work as described below at the.....

Shell Oil Company Selman Well No. 1 in "1" (Company or Operator) (Unit)
NE 1/4 SE 1/4 of Sec. 22, T. 12-S, R. 37-E, NMPM, Gladiola Area Pool
(40-acre Subdivision)
Lea County.

FULL DETAILS OF PROPOSED PLAN OF WORK
(FOLLOW INSTRUCTIONS IN THE RULES AND REGULATIONS)

We propose to plug and abandon Selman No. 1 as following:

1. Run drill pipe to TD (9852') open ended.
2. Pick up drill pipe approximately one foot (1') off bottom and circulate drill pipe clear of air
3. Pump 20 barrels of water ahead of cement, mix and displace 100 sacks of neat cement for bottom plug - 9500' to TD 9852'.
4. Follow cement with 20 barrels of water and displace with mud.
5. Following calculated displacement, pick up drill pipe and come out of the hole.
6. After WOC 12 hours go back in the hole with drill pipe to check top of plug.
7. After checking bottom plug, pull back up the hole to bottom of 8-5/8" casing at 4550' and spot 50 sacks of neat cement, pumping 20 barrels of water ahead and behind cement, using calculated displacement to spot cement plug.
8. After WOC 12 hours check top of plug at approximately 4400 feet, pull back to surface and spot 10 sacks of neat cement in top of 8-5/8" casing and fill in cellar.
9. Erect 4" marker 4' above ground level as required by Rule 202.

Approved....., 19.....
Except as follows:

Approved
OIL CONSERVATION COMMISSION

By.....

Title.....

By.....

Position.....
Send Communications regarding well to:

Name.....

Address.....

