

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

<p align="center">SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)</p>		<p>5a. Indicate Type of Lease State <input type="checkbox"/> Fee <input checked="" type="checkbox"/></p>
<p>1. Name of Operator Cabot Corporation</p>		<p>5. State Oil & Gas Lease No.</p>
<p>2. Address of Operator P. O. Box 1101, Pampa, Texas 79065</p>		<p>7. Unit Agreement Name</p>
<p>3. Location of Well UNIT LETTER 0 990 FEET FROM THE South LINE AND 1650 FEET FROM THE East LINE, SECTION 35 TOWNSHIP 13-S RANGE 37E N.M.P.M.</p>		<p>8. Farm or Lease Name Howard Fleet</p>
<p>15. Elevation (Show whether DF, RT, GR, etc.) 3846 Gr.</p>		<p>9. Well No. 4</p>
<p>10. Field and Pool, or Wildcat King Field SWD</p>		<p>12. County Lea</p>

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

<p>PERFORM REMEDIAL WORK <input type="checkbox"/></p> <p>TEMPORARILY ABANDON <input type="checkbox"/></p> <p>DRILL OR ALTER CASING <input type="checkbox"/></p> <p>OTHER <input type="checkbox"/></p>	<p>PLUG AND ABANDON <input checked="" type="checkbox"/></p> <p>CHANGE PLANS <input type="checkbox"/></p>	<p>REMEDIAL WORK <input type="checkbox"/></p> <p>COMMENCE DRILLING OPNS. <input type="checkbox"/></p> <p>CASING TEST AND CEMENT JOB <input type="checkbox"/></p> <p>OTHER <input type="checkbox"/></p>	<p>ALTERING CASING <input type="checkbox"/></p> <p>PLUG AND ABANDONMENT <input type="checkbox"/></p>
---	--	--	--

7. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

The following is our proposed plugging procedure:

1. Hole will be loaded with mud laden fluid.
2. Plug #1 - 100 sacks of cement will be pumped below Baker Model "D" Packer set at 4600'.
3. Cut and pull 5½" casing at 4590'.
4. Plug #2 - 25 sacks cement from 4540' to 4640'.
5. Plug #3 - 10 sacks cement from 0' to 20'.
6. A 4"x4' steel marker set in concrete with name and location engraved on marker.
7. The estimated date for this work is 9-3-75.

→ 100' plug inside 8-5/8" at Top of salt.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

<p>SIGNED <u>John Runyan</u> Original Signed by John Runyan Geologist</p>	<p>TITLE Agent</p>	<p>DATE August 26, 1975</p>
<p>APPROVED BY _____</p>	<p>TITLE _____</p>	<p>DATE _____</p>

CONDITIONS OF APPROVAL, IF ANY: