Submit 3 Copies to Appropriate District Office

APPROVED BY

CONDITIONS OF APPROVAL, IF ANY:

State of New Mexico Energy, Minerals and Natural Resources Department

Form C-103 Revised 1-1-89

- DATE -

OIL CONSERVATION DIVISION DISTRICT I WELL API NO. P.O. Box 1980, Hobbs, NM 88240 P.O. Box 2088 30-025- のちのデ DISTRICT II Santa Fe, New Mexico 87504-2088 P.O. Drawer DD, Artesia, NM 88210 5. Indicate Type of Lease STATE FEE 6. State Oil & Gas Lease No. 1000 Rio Brazos Rd., Aztec, NM 87410 7169 SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A 7. Lease Name or Unit Agreement Name DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.) Type of Well: GAS WELL State E 7169 \mathbf{X} WELL OTHER 2. Name of Operator 8. Well No. Kerr-McGee Corporation 3. Address of Operator 9. Pool name or Wildcat King Wolfcamp U.S. Onshore Region, Box 25861, OK City, OK 4. Well Location ___ Line and 1650 : 330 Feet From The West south Unit Letter Feet From The 37E 36 13S Lea Township Range **NMPM** Section County 10. Elevation (Show whether DF, RKB, RT, GR, etc.) 3843.9' GR Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data 11. NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF: X PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORK ALTERING CASING **CHANGE PLANS** TEMPORARILY ABANDON COMMENCE DRILLING OPNS. PLUG AND ABANDONMENT CASING TEST AND CEMENT JOB **PULL OR ALTER CASING** OTHER: OTHER:_ 12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103. on that we rele See attached P&A procedure I hereby certify that the juformation above is true and complete to the best of my knowledge and belief. ____ Analyst II Bunas SIGNATURE -TYPE OR PRINT NAME (This space for State Use)
ORIGINAL SIGNED BY JERRY SEXTON DISTRICT I SUPERVISOR

- TITLE -

State E-1 7169 King Field, Lea County, New Mexico P & A Procedure

- 1. File intent to P&A w/ NMCC.
- 2. MIRU workover unit. PCCH-Lords and pump.
- 3. ND tree, NU BOP's.
- 4. TOOH w/ tubing, LD anchor, & S/N.
- 5. RU wireline co., dump bail 2 sx cement on CIBP @ 9600'
- 6. GIH w/ CIBP & set @ +/- 9300'.
- 7. PU workstring and TIH.
- 8. Cap CIBP w/ 20' cement.
- 9. Circulate hole full w/ 9.5 ppg mud. TOOH w/ tbg.
- 10. RU casing pullers, find freepoint, shoot off 5 1/2" casing. LD casing.
- 11. TIH w/ tubing, find top of 5 1/2" casing, pump balanced cement plug 50' inside and 50' outside stub.
- 10. Set 100' balanced plug @ bottom 9 5/8" casing (4580').
- 11. Tag plug w/ tubing.
- 12. LD tubing.
- 13. Pump 4'- 14' cmt. plug @ surf.
- 14. Cut casing off 3' below ground level & weld on plate.
- 15. Restore location.

of of.

5-9-89 PND