

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease
State <input type="checkbox"/> <b>Federal</b> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.

## SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator <b>McAlester Fuel Company</b>	8. Farm or Lease Name <b>New Mexico Federal</b>
3. Address of Operator <b>P. O. Box 210, Magnolia, Arkansas</b>	9. Well No. <b>A-2</b>
4. Location of Well UNIT LETTER <b>J</b> <b>1980</b> FEET FROM THE <b>South</b> LINE AND <b>1980</b> FEET FROM THE <b>East</b> LINE, SECTION <b>6</b> TOWNSHIP <b>12S</b> RANGE <b>38E</b> NMPM.	10. Field and Pool, or Wildcat <b>Gladiola Devonian</b>
15. Elevation (Show whether DF, RT, GR, etc.) <b>3891 DF</b>	12. County <b>Lea</b>

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input checked="" type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Would like to amend plans sent February 24, 1965. To read:

Plan to set 100' cement plug from 10,900' to 11,000'  
After WOC - Perforate and test 9530' to 9540' and 9962' to 9967'  
If neither of the above zones produce, a bridge plug would be set at 9500'  
and 100' cement plug set from 9400' to 9500'.  
Shoot off casing between 9300' and 9360'. Recover 5½" casing.  
Plan to set 100' cement plug from 7800' to 7900' in a mud laden fluid in hole  
100' cement plug from 5100' to 5200' in a mud laden fluid in hole  
100' cement plug from 4450' to 4550' in a mud laden fluid in hole  
20' cement plug at surface.

No attempt will be made to pull any 9 5/8" or 13 3/8" casing

Will erect surface monument.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Charles H. ... TITLE Gen. Prod. Supt. DATE March 16, 1965

APPROVED BY ... TITLE ... DATE ...

CONDITIONS OF APPROVAL, IF ANY: