

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Orig&2cc: CCC, Hobbs
cc: Regional Office
cc: file

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease
State <input type="checkbox"/> Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator SINCLAIR OIL & GAS COMPANY	8. Farm or Lease Name Henry A. Harris
3. Address of Operator P. O. Box 1920, Hobbs, New Mexico 88240	9. Well No. 1
4. Location of Well UNIT LETTER H 1980 FEET FROM THE North LINE AND 660 FEET FROM THE East LINE, SECTION 18 TOWNSHIP 12S RANGE 38E NMPM.	10. Field and Pool, or Wildcat Gladiola Devonian
15. Elevation (Show whether DF, RT, GR, etc.) 3868' GR	12. County Lea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>
OTHER <input type="checkbox"/>	OTHER <input type="checkbox"/>
PLUG AND ABANDON <input checked="" type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
CHANGE PLANS <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1703.

FBTD 11,987' - 13-3/8"OD 35.6# casing set @ 303' and 400 sacks cement circulated to surface.
9-5/8"OD 36# and 40# casing set @ 4,494' and 2600 sacks cement circulated.
7"OD 26#, 29# and 32# casing set @ 11,987' and cemented w/100 sacks. Cement top @ 10,730' from surface.

7"OD casing perforated 11,970-11,987'.

PROPOSE TO PLUG AND ABANDON AS FOLLOWS:

Place heavy mud between all plugs.

Set C.I. plug @ 11,900' w/2 sacks cement on top.

Cut off and pull 5,000' of 7"OD casing, spot 25 sacks cement in top of 7"OD casing stub.


Spot 25 sacks cement plug @ bottom of 9-5/8"OD casing @ 4494'.


Cut off and pull 500' of 9-5/8"OD casing, spot 25 sacks cement in top of 9-5/8"OD casing stub.

Spot 25 sacks cement plug @ bottom of 13-3/8"OD surface casing @ 303'.

Cut off surface casing 5' below ground level, load hole from a depth of 20' to the surface w/cement. Set regulation dry hole marker, clean and level location.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED  TITLE Superintendent DATE 4-5-68

APPROVED BY  TITLE SUPERVISOR DATE APR 6 1968

CONDITIONS OF APPROVAL, IF ANY: