

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Orig&2cc: OCC, Hobbs
cc: Regional Office
cc: file

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease
State <input type="checkbox"/> Fee <input checked="" type="checkbox"/>

5. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator SINCLAIR OIL & GAS COMPANY	8. Farm or Lease Name Henry A. Harris
3. Address of Operator P. O. Box 1920, Hobbs, New Mexico 88240	9. Well No. 4
4. Location of Well UNIT LETTER C 1980 FEET FROM THE North LINE AND 1980 FEET FROM THE East LINE, SECTION 18 TOWNSHIP 12S RANGE 38E NMPM.	10. Field and Pool, or Wildcat Gladiola Devonian
15. Elevation (Show whether DF, RT, GR, etc.) 3870' GR	12. County Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1109.

FBTD 11,984' - 13-3/8"OD 35.6# casing set @ 324' and cemented w/350 sacks cement. Circulated to surface.
9-5/8"OD 36# and 40# casing set @ 4540' and cemented w/1700 sacks cement. Top cement @ 1600' from the surface.
5-1/2"OD 17# and 20# casing set @ 11,985' and cemented w/150 sacks. Top of cement @ 11,140' from surface.

5-1/2"OD casing perforated 11,970-11,980'.

PROPOSE TO PLUG AND ABANDON AS FOLLOWS:

Place heavy mud between all plugs.

Set C.I. plug @ 11,900' w/2 sacks cement on top.

Cut off and pull approx. 5,000' of 5-1/2"OD casing, spot cement plug, 25 sacks in top of 5-1/2"OD casing stub.

Spot 25 sacks cement plug @ bottom of 9-5/8"OD casing @ approx. 4540' and cut off and pull approx. 500' of 9-5/8"OD casing.

Spot 25 sacks cement plug in top of 9-5/8"OD casing stub.

Spot 25 sacks cement plug in bottom of 13-3/8"OD casing @ approx. 324'.

Cut off surface casing 5' below ground level, load hole from a depth of 20' to the surface w/cement plug. Set regulation dry hole marker, clean and level location.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED [Signature] TITLE Superintendent DATE 4-5-68

APPROVED BY [Signature] TITLE SON DATE 1968

CONDITIONS OF APPROVAL, IF ANY: