

Submit 3 Copies
to Appropriate
District Office

State of New Mexico
Energy, Minerals and Natural Resources Department

Form C-103
Revised 1-1-89

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

OIL CONSERVATION DIVISION
P.O. Box 2088
Santa Fe, New Mexico 87504-2088

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

WELL API NO. 30-025-07237
5. Indicate Type of Lease STATE <input type="checkbox"/> FEE <input checked="" type="checkbox"/>
6. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)		7. Lease Name or Unit Agreement Name H. H. Harris "A"	
1. Type of Well: OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	8. Well No. #1		
2. Name of Operator Devon Energy Corporation	9. Pool name or Wildcat Bronco/Wolfcamp Dev.		
3. Address of Operator 20 N. Broadway Suite 1500 OKC, OK 73102			
4. Well Location Unit Letter <u>A</u> : <u>990</u> Feet From The <u>north</u> Line and <u>571</u> Feet From The <u>east</u> Line Section <u>11</u> Township <u>13S</u> Range <u>38E</u> NMPM Lea County	10. Elevation (Show whether DF, RKB, RT, GR, etc.) 3819'		

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>		CASING TEST AND CEMENT JOB <input type="checkbox"/>	
OTHER: _____ <input type="checkbox"/>		OTHER: _____ <input type="checkbox"/>	

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

We plan to plug and abandon this well as follows:

- Set a CIBP at 9400' and dump 35' of cement on top.
- Set a plug at 5985' and lift cement above the previously squeezed hole in the casing (5948'-5979').
- Set a plug 50' above and below the 9 5/8" casing shoe. *will need to perf 7"*
- Set a 100' plug at 2270'.
- Set a plug 50' above and below the 13 3/8" casing shoe.
- Set a 10 sx cement plug at surface. *will need to perf 7" & 9 1/2"*
- After setting the required plugs, load the hole with 10# brine + 25/bbl gel.

Casing in hole: 13 3/8" @ 334'; 9 5/8" @ 4685'; 7" @ 11904'
TOC = 575' on intermediate casing and 8448' on production casing

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Debby O'Donnell TITLE Engineering Technician DATE 10/19/93
 TYPE OR PRINT NAME Debby O'Donnell TELEPHONE NO 552-4511
 (405)

(This space for State Use)

ORIGINAL SIGNED BY JERRY SEXTON
DISTRICT I SUPERVISOR

APPROVED BY _____ TITLE _____ DATE OCT 25 1993

CONDITIONS OF APPROVAL, IF ANY: