

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION
P.O. Box 2088
Santa Fe, New Mexico 87504-2088

WELL API NO. 30-025-21287
5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No. K-1038
7. Lease Name or Unit Agreement Name State C
8. Well No. 1
9. Pool name or Wildcat Nonombre Upper Penn
10. Elevation (Show whether DF, RKB, RT, GR, etc.) 3168' GR

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT"
(FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well:
OIL WELL ☒ GAS WELL ☐ OTHER ☐

2. Name of Operator
YATES PETROLEUM CORPORATION

3. Address of Operator
105 South 4th St., Artesia, NM 88210

4. Well Location
Unit Letter K : 1980 Feet From The South Line and 1980 Feet From The West Line
Section 32 Township 13S Range 34E NMPM Lea County

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
OTHER: <u>Propose to Drill retainer, perforate</u> <input checked="" type="checkbox"/> <u>treat</u>	PLUG AND ABANDONMENT <input type="checkbox"/>
	CASING TEST AND CEMENT JOB <input type="checkbox"/>
	OTHER: <input type="checkbox"/>

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Current perforations: 10312-22'; 10344-60'; 10373-82'; 10493-99'.
Propose to squeeze excessive water in Ranger Lake zone with X-linked polymers. Sand jet and test Range Lake for oil production as follows:
1) Drill out cement retainer @ 10660'.
2) Drill out CIBP @ 10710'.
3) Perforate 10757-10765' (20 holes). Acidize w/700 gals 15% HCL acid.
4) Pump 1000 bbls X-linked ploymer solution into perfs @ 10757-65'.
5) Set RBP @ 10740'. Set packer @ 10700'.
6) Perforate 10715, 717, 719' (12 holes). Acidize w/500 gals 15% HCL acid.
7) Swab back load.
8) Pump 1000 bbls X-linked polymer solution into perfs @ 10715-719'. SI well for 5 days.
9) Set RBP @ 10710'; TOH w/tubing and packer.
10) Sand jet 2 hole @ 10698' and 2 holes @ 10695'. Set packer @ 10670'. Swab/evaluate well.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.
SIGNATURE Juanita Goodlett TITLE Production Supervisor DATE 1-8-92
TYPE OR PRINT NAME Juanita Goodlett TELEPHONE NO. 505/748-1471

(This space for State Use)
APPROVED BY Paul Kanta TITLE Geologist DATE JAN 13 '92
CONDITIONS OF APPROVAL, IF ANY: