

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

HOBBBS OFFICE O. C. C.  
NEW MEXICO OIL CONSERVATION COMMISSION

MAY 14 4 53 PM '69

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. <b>7272</b>	
7. Unit Agreement Name	
8. Farm or Lease Name <b>Lea "IV" State</b>	
9. Well No. <b>1</b>	
10. Field and Pool, or Wildcat <b>Lazy J</b>	
12. County <b>Lea</b>	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>
2. Name of Operator <b>Gulf Oil Corporation</b>
3. Address of Operator <b>Box 670, Hobbs, New Mexico 88240</b>
4. Location of Well UNIT LETTER <b>P</b> <b>660</b> FEET FROM THE <b>South</b> LINE AND <b>660</b> FEET FROM THE <b>East</b> LINE, SECTION <b>26</b> TOWNSHIP <b>13-S</b> RANGE <b>33-E</b> NMPM. 15. Elevation (Show whether DF, RT, GR, etc.) <b>4204' GL</b>

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data  
NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input checked="" type="checkbox"/> <b>Plug and Abandon</b>

SUBSEQUENT REPORT OF:

REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

9917' TD, 9871' PB.

It is proposed to plug and abandon as follows: Load hole with fresh water Bentonite mud. Spot 15 sack cement plug No. 1 from 9700' to 9500'. Shoot 5-1/2" casing off at approximately 8200' and recover casing. Spot 30 sack cement plug No. 2 from 8250' to 8150'. (Across 5-1/2" casing stub); 45 sack cement plug No. 3 from 7650' to 7550'; 50 sack cement plug No. 4 from 5550' to 5450'; 40 sack cement plug No. 5 from 4250' to 4150'. (Across 8-5/8" shoe at 4200'). \*\* Out 8-5/8" casing at free point and recover casing providing free point is below 725', if not, casing will not be out. Spot 50 sack cement plug No. 6 in and out of 8-5/8" casing stub; 60 sack cement plug No. 7 from 1800' to 1700'; 65 sack cement plug No. 8 from 425' to 325'. (Across 13-3/8" shoe at 374'), and 40 sack cement plug No. 9 from 50' to surface. Clean location and install dry hole marker.

\* 25 SX

\*\* of sack as exposed 2500' Bone 425' to Top of 9' SX

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <b>C. D. BORLAND</b>	TITLE <b>Area Production Manager</b>	DATE <b>May 13, 1969</b>
APPROVED BY <b>Lester H. Clements</b>	TITLE <b>Chief Engineer</b>	DATE <b>MAY 15 1969</b>
CONDITIONS OF APPROVAL, IF ANY:		