

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
GEOLOGICAL SURVEY

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir. Use Form 9-331-C for such proposals.)

1. oil ☒ gas ☐ other ☐  
well well

2. NAME OF OPERATOR  
TEXACO PRODUCING INC.

3. ADDRESS OF OPERATOR  
P.O. BOX 728, HOBBS, N.M. 88240

4. LOCATION OF WELL (REPORT LOCATION CLEARLY. See space 17 below.)  
AT SURFACE: Unit Ltr K, 1650 FSL & 2310 FWL  
AT TOP PROD. INTERVAL:  
AT TOTAL DEPTH:

16. CHECK APPROPRIATE BOX TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

REQUEST FOR APPROVAL TO:	SUBSEQUENT REPORT OF:
TEST WATER SHUT-OFF <input type="checkbox"/>	<input type="checkbox"/>
FRACTURE TREAT <input type="checkbox"/>	<input type="checkbox"/>
SHOOT OR ACIDIZE <input type="checkbox"/>	<input checked="" type="checkbox"/>
REPAIR WELL <input type="checkbox"/>	<input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	<input type="checkbox"/>
MULTIPLE COMPLETE <input type="checkbox"/>	<input type="checkbox"/>
CHANGE ZONES <input type="checkbox"/>	<input type="checkbox"/>
ABANDON* <input type="checkbox"/>	<input type="checkbox"/>
(other) <input type="checkbox"/>	<input type="checkbox"/>

5. LEASE  
NM-01124

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME  
Willard Beaty

9. WELL NO.  
3

10. FIELD OR WILDCAT NAME  
Lazy J Penn

11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA  
Sec. 35, T-13S-R-33E

12. COUNTY OR PARISH  
Lea

13. STATE  
NM

14. API NO.

15. ELEVATIONS (SHOW DF, KDB, AND WD)  
4217' DF

(NOTE: Report results of multiple completion or zone change on Form 9-330.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)\*

1. Rig up. Install BOP. POH w/prod. equipment.
2. C/O if necessary.
3. Set pkr. at + 9775'.
4. Acidize the Bough "C" perfs 9807-22' and 9834'-38', w/10,000 gal of 20% gelled acid w/30% CO<sub>2</sub>.
5. POH w/pkr.
6. Run log, GR/OCL. Log from PBTD 9843' to + 9650'.
7. Perforate w/2 SPF Bough "A" 9700-27' (56 holes)  
Bough "B" 9754-71' (36 holes)
8. Set RBP at + 9790' and set pkr at + 9500'.
9. Acidize new perfs 9700-27' and 9754-71' w/4500 gal of 20% gelled acid w/150 ball sealers. POH w/pkr.
10. Retrieve RBP. 11. Swab well and evaluate. 12. Install prod. equip. Test & place  
Subsurface Safety Valve: Manu. and Type \_\_\_\_\_ Set @ \_\_\_\_\_ Ft. on  
production.

18. I hereby certify that the foregoing is true and correct

SIGNED R. Frank Gray TITLE DIST. OPR. MGR. DATE 8/15/85

(This space for Federal or State office use)

APPROVED BY \_\_\_\_\_ TITLE \_\_\_\_\_ DATE \_\_\_\_\_  
CONDITIONS OF APPROVAL AS ANY

AUG 20 1985

