

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

OIL CONSERVATION DIVISION

P.O. Box 2088
Santa Fe, New Mexico 87504-2088

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

WELL API NO. <u>30-025-22357</u> <u>3025223700</u>	
5. Indicate Type of Lease	STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No. <u>K-4177</u>	
7. Lease Name or Unit Agreement Name State "32"	
8. Well No. <u>1</u>	
9. Pool name or Wildcat <u>Wildcat Wolfcamp</u>	
10. Elevation (Show whether DF, RKB, RT, GR, etc.) <u>4263.8 Gr</u>	

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well:
OIL WELL ☒ GAS WELL ☐ OTHER ☐

2. Name of Operator
Coastal Oil & Gas Corporation

3. Address of Operator
P. O. Box 235, Midland, Texas 79702

4. Well Location
Unit Letter L : 1980 Feet From The South Line and 660 Feet From The West Line
Section 32 Township 13-S Range 33-E NMMPM Lea County

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data
NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐
PULL OR ALTER CASING ☐
OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐
COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐
CASING TEST AND CEMENT JOB ☐
OTHER: ☐

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

NOTE: Previously abandoned Bough "C" perfs with a CIBP at 9741' with 35' of cement on top. PBTD 9706'.

1. POOH with rods and tbg.
2. Set CIBP at 9010' (Wolfcamp perfs at 9066'-81'). Dump 35' of cmt on top. Circ hole with 9.5 PPG mud.
3. Cut 5-1/2" csg at \pm 6000'. LD same.
4. GIH with tubing to 5-1/2" casing stub, spot 100' plug from 50' below stub to 50' above.
5. Spot 100' cmt plug from 4093-3993' (8-5/8" csg at 4043').
6. Perf 4 holes at 1650' (T/Salt). Squeeze with 75 sacks (100' of annulus fill and 100' inside 8-5/8").
7. Cut 8-5/8" csg at 800'. Pull and LD same.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Bobby L. Smith TITLE Sr. Petroleum Engineer DATE 6-1-92

TYPE OR PRINT NAME Bobby L. Smith

TELEPHONE NO. 915 682-7925

(This space for State Use)

Orig. Signed by
Paul Kautz
Geologist

APPROVED BY

TITLE

DATE

JUN 05 '92

CONDITIONS OF APPROVAL, IF ANY:

THE COMMISSION MUST BE NOTIFIED 24 HOURS PRIOR TO THE BEGINNING OF PLUGGING OPERATIONS, FOR THE CIBP.

State "32" No. 1
Page Two

8. Spot 50 sack plug from 50' inside 8-5/8" stub to 50' above (35 sacks).
9. Spot 55 sack plug from 402-302' (13-3/8" at 352').
10. Spot 10 sack surface plug.
11. Install P&A marker. Clean and level location.